


Service
Service
Service



CL 9453028, 1000 400
190495

Service Manual

Contents	Page
1. Technical Specifications	2
2. Safety- and maintenance instructions, warnings and notes.	3
3. Directions for use	4
4. Mechanical instructions	5
5. Faultfinding and repair tips	8
6. Faultfinding trees	15
Supply voltage diagram	19
Blockdiagram	20
Testpointoverview and oscillograms	21
7. <i>Electrical diagram's en PWB's</i>	<i>Diagram PWB</i>
Power supply (Diagram A1)	22 31,32
Diversity table A1	23
Horizontal deflection (Diagram A2)	24 31,32
Vertical deflection (Diagram A3)	25 31,32
Synchronisation (Diagram A4)	25 31,32
Tuner en video IF (TDA 8844) (Diagram A5)	26 31,32
Tuner en video IF (TDA 8845) (Diagram A5)	27 31,32
Diversity table A5	28
Front control (Diagram A8)	28 31,32
Video processing (Diagram A6)	29 31,32
Control (Diagram A7)	30 31,32
AM Mono demodulator (Diagram A9)	33 31,32
Smart sound & mono amplifier (Diagram A10)	34 31,32
Front cinch and headphone (Diagram A11)	35 31,32
Rear IO Scart (Diagram A13)	36 31,32
CRT Panel (Diagram B)	37 38
ITT Audio decoding (Diagram D1)	39 38
ITT Audio amplifier (Diagram D2)	40 38
Side AV panel (Diagram E)	41 41
8. Alignments	43
9. Circuit description new circuits and list of abbreviations	47 52
10. Spareparts list	55

©Copyright reserved 1999 Philips Consumer Electronics B.V. Eindhoven, The Netherlands. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.



1. Technical Specifications

1.1 Specifications


Mains voltage 150V - 276Vac;
 Mains frequency 50 - 60Hz
 Maximum power consumption
 • 14" : 40W +/- 10%
 • 20" : 56W +/- 10%
 • 21" : 58W +/- 10%
 Standby power consumption 10W +, 10%
 Max. Antenne-input

Off air 100dBV
 On air 90dBV


Audio output
 • Stereo : 2 * 3W; 2 * 1W
 • Mono : 2 * 2W; 4W; 3W; 2W; 1W

Tuners
 • UV 1316/AI-2 (PAL)
 • UV 1316/AIU-2 (PAL)
 • UV 1356C/AI (PAL)

1.2 Specification of the terminal sockets



CL 86532104_011.eps
080299



CL 86532104_012.eps
080299

1.2.1 EXT1 CVBS(in/out) + RGB(in) - tuner at output

- 1 - Audio Out R (0.5VRMS (1kΩ) ⊕
- 2 - Audio In R (0.2-2VRMS (10kΩ) ⊕
- 3 - Audio Out L (0.5VRMS (1kΩ) ⊕
- 4 - Earth screen ⊥
- 5 - Earth screen ⊥
- 6 - Audio In L (0.2-2VRMS (10kΩ) ⊕
- 7 - Blue (0.7Vpp/75) ⊕
- 8 - CVBS status (INT = 0-2V, EXT (16:9) = 4.5-7V, EXT(4:3) = 9.5 -12V) ⊕
- 9 - Earth screen ⊥
- 10 - ⊥
- 11- Green (0.7Vpp/75) ⊕
- 12 - ⊥
- 13- Earth screen ⊥
- 14- Earth screen ⊥
- 15- Red (0.7Vpp/75) ⊕
- 16- FBL (<0.9V RGB mode) ⊕
- 17- Earth screen ⊥
- 18- Earth screen ⊥
- 19- CVBS ⊕
- 20- CVBS (1Vpp/75) ⊕
- 21- Earth screen ⊥

1.2.2 EXT2 CVBS (in/out) + SVHS(in)

- Input = EXT2 => output = tuner
 Input = tuner/EXT1 =>output = tuner/EXT11
- 1 - Audio Out R (0.5VRMS (1kΩ) ⊕
 - 2 - Audio In R (0.2-2VRMS (10kΩ) ⊕
 - 3 - Audio Out L (0.5VRMS (1kΩ) ⊕
 - 4 - Earth screen ⊥
 - 5 - Earth screen ⊥
 - 6 - Audio In L (0.2-2VRMS (10kΩ) ⊕
 - 7 - ⊥
 - 8 - CVBS status (INT = 0-2V, EXT (16:9) = 4.5-7V, EXT(4:3) = 9.5 -12V) ⊕
 - 9 - Earth screen ⊥
 - 10 - ⊥
 - 11 - ⊥
 - 12 - ⊥
 - 13- Earth screen ⊥
 - 14- Earth screen ⊥
 - 15- C (300mVpp/75) ⊕
 - 16 - ⊥
 - 17- Earth screen ⊥
 - 18- Earth screen ⊥
 - 19- CVBS ⊕

20- CVBS (1Vpp/75)
21- Earth screen



L - Audio L (red) (0.2-2Vrms 10kΩ)
R - Audio R (white) (0.2-2Vrms 10kΩ)



1.2.3 Cinch - audio/video in

V - CVBS (yellow) (1Vpp/75)




1.2.4 Headphone

8-600Ω (4mW)



1.3 PCB location drawing



2. Safety instructions, maintenance instruction, warnings and Notes

2.1 Safety instructions for repairs ▲

1. Safety regulations require that during a repair:
 - The set should be connected to the mains via an isolating transformer;
 - Safety components, indicated by the symbol ▲, should be replaced by components identical to the original ones;
 - When replacing the CRT, safety goggles must be worn.
2. Safety regulations require that after a repair the set must be returned in its original condition. In particular attention should be paid to the following points.
 - As a strict precaution, we advise you to resolder the solder joints through which the horizontal deflection current is flowing, in particular ('general repair instruction'):
 - All pins of the line output transformer (LOT);
 - Fly-back capacitor(s);
 - S-correction capacitor(s);
 - Line output transistor;
 - Pins of the connector with wires to the deflection coil;

- Other components through which the deflection current flows.
 - Note:
 - This resoldering is advised to prevent bad connections due to metal fatigue in solder joints and is therefore only necessary for television sets older than 2 years.
- The wire trees and EHT cable should be routed correctly and fixed with the mounted cable clamps.
 - The insulation of the mains lead should be checked for external damage.
 - The mains lead strain relief should be checked for its function in order to avoid touching the CRT, hot components or heat sinks.
 - The electrical DC resistance between the mains plug and the secondary side should be checked (only for sets which have a mains isolated power supply). This check can be done as follows:
 - Unplug the mains cord and connect a wire between the two pins of the mains plug;
 - Set the mains switch to the "on" position (keep the mains cord unplugged!);
 - Measure the resistance value between the pins of the mains plug and the metal shielding of the tuner

or the aerial connection on the set. The reading should be between 4.5 M Ω and 12 M Ω

- Switch off the TV and remove the wire between the two pins of the mains plug.
- The cabinet should be checked for defects to avoid touching of any inner parts by the customer.

2.2 Maintenance instruction

It is recommended to have a maintenance inspection carried out by a qualified service employee. The interval depends on the usage conditions:

- When the set is used under normal circumstances, for example in a living room, the recommended interval is 3 to 5 years.
- When the set is used in circumstances with higher dust, grease or moisture levels, for example in a kitchen, the recommended interval is 1 year.
- The maintenance inspection contains the following actions:
 - Execute the above mentioned 'general repair instruction'.
 - Clean the power supply and deflection circuitry on the chassis.
 - Clean the picture tube panel and the neck of the picture tube.

2.3 Warnings

1. ESD 
2. All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the set by a wristband with resistance. Keep components and tools also at this same potential.
3. Available ESD protection equipment:
 - Complete kit ESD3 (small table mat, Wristband, Connection box, Extension cable and Earth cable) 4822 310 10671
 - Wristband tester 4822 344 13999
4. In order to prevent damage to ICs and transistors, all high-voltage flashovers must be avoided. In order to prevent damage to the picture tube, the method shown in Fig. 2.1 should be used to discharge the picture tube. Use a high-voltage probe and a multimeter (position DC-V). Discharge until the meter reading is 0V (after approx. 30s).
5. Together with the deflection unit and any multipole unit, the flat square picture tubes used form an integrated unit. The deflection and the multipole units are set optimally at the factory. Adjustment of this unit during repair is therefore not recommended.
6. Be careful during measurements in the high-voltage section and on the picture tube.
7. Never replace modules or other components while the unit is switched on.
8. When making settings, use plastic rather than metal tools. This will prevent any short circuits and the danger of a circuit becoming unstable.
9. Wear safety goggles during replacement of the picture tube.


2.4 Notes

The direct voltages and oscillograms should be measured with regard to the tuner earth () or hot earth () as this is called. The direct voltages and oscillograms shown in the diagrams are indicative and should be measured in the Service Default Mode (see chapter 8) with a colour bar signal and stereo sound (L:3 kHz, R:1 kHz unless stated otherwise) and picture carrier at 475.25 MHz.

Where necessary, the oscillograms and direct voltages are measured with () and without aerial signal (). Voltages in the power supply section are measured both for normal operation () and in standby (). These values are indicated by means of the appropriate symbols.

The picture tube PWB has printed spark gaps. Each spark gap is connected between an electrode of the picture tube and the Aquadag coating.

The semiconductors indicated in the circuit diagram and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.



CL 26532098/042
140792

Figure 2-1

3. Directions for use


Tuning in to channels

Quick installation (first use)

The following operations are all described in the enclosed quick installation guide. We advise you to use it. The first time you switch on the television, a menu appears on the screen. This menu asks you to choose the language of the other menus. If the menu does not appear, hold down the PROGRAM- and PROGRAM+ keys on the set for 4 seconds to bring it up.


- 1 Use the keys numbered ① to ③ on the remote control to choose your language (for English, press ①). Another menu appears.
- 2 Select your country (for GB, press ②).
- 3 As soon as your country is entered, tuning in starts automatically. The operation takes a few minutes. A display shows the search status and the number of programmes found. When it has finished, the menu disappears and the last programme is displayed. If no programmes are found, refer to the chapter entitled *Tips* on p. 10.
- 4 If the transmitter or the cable network broadcasts the automatic sort signal, the programmes will be correctly numbered.
- 5 If not, the programmes found will be numbered in descending order starting at 99, 98, 97, etc. (or 79, 78, ...). Use the SORT menu to renumber them.

Some transmitters or cable networks broadcast their own sort parameters (region, language, etc.). Where this is the case, make your choice using the ④ keys and confirm with ⑤.



To renumber the programmes found


- 1 Press the ④ key. The main menu is displayed.
- 2 Press ① once to select INSTALLATION, then press ②. The INSTALLATION menu appears. The LANGUAGE option is activated.
- 3 Press ③ 3 times to select SORT then press ④. The SORT menu appears. The FROM option is activated.
- 4 Select the programme you wish to renumber using keys ① to ③. Example: to renumber programme 78 as 2, press ⑦ ⑧.
- 5 Select option A (key ①) and enter the new number with keys ① to ③ (for the example given, enter 2).
- 6 Select EXCHANGE (key ①), and press ②. The message EXCHANGED appears, the exchange takes place (④ to cancel). In our example, programme 78 is renumbered as 2 (and programme 2 as 78).
- 7 Select the option FROM (key ①) and repeat stages ④ to ⑥ as many times as there are programmes to renumber.
- 8 To exit from the menus, press ⑤.



Manual tuning


This menu allows you to store the programmes one by one.

- 1 Press ⑤. The main menu comes up on the screen.
- 2 Press ① once to select INSTALLATION then press ②.
- 3 Select MANUAL STORE (①) and press ②. The MANUAL STORE menu appears.
- 4 Select SYSTEM (only available on certain models). Use ② to choose UK (standard I), FRANCE (standard LL) or WEST-EU (standard BG reception).
- 5 Select SEARCH and press ②. The search begins. As soon as a programme is found, the search will stop. If you know the frequency of the programme required, simply enter its number using keys ① to ③.
- 6 If reception is unsatisfactory, select FINE TUNE and press ① or ② to fine tune.
- 7 Select PROGRAM NO. and enter the required programme number using ① to ③ or ④ to ⑤.
- 8 Select STORE and press ②. The message STORED appears. The programme has been stored.
- 9 Repeat steps ⑤ to ⑧ as many times as there are programmes to store. To exit the menus, press ⑤.




Other settings on the INSTALLATION menu

- 1 Press ⑤. The main menu is displayed on-screen.
- 2 Press ① once to select INSTALLATION and press ②. The INSTALLATION menu appears.
- 3 Use ① to select a setting and ② to adjust.
 - LANGUAGE: to change the menu language.
 - COUNTRY: to select the country you are in (GB for Great Britain).
 This setting affects the automatic programme sort.
- 4 AUTOSTORE: press ② to begin storing. The operation takes a few minutes. When it is complete, the INSTALLATION menu reappears automatically. For more information, see the Quick Installation chapter, steps ③ to ⑤ on the previous page.
 - To exit or interrupt the search, press ⑤.
 - EXTERNAL: press ② to bring up the menu. You have access to a series of names which allow you to customise the names of the external sockets. When you next select an external socket, its chosen name will be displayed for a few seconds.
- 5 To exit from the menus, press ⑤.



Using other menus

To adjust a menu:



Note: the menus disappear automatically after 30 seconds if no further adjustments are made. To exit from the menus, press **EXIT** (or **BACK**) to come back to the previous stage).

Adjusting the picture

Press **HOME**. You can adjust: BRIGHTNESS, COLOUR, CONTRAST, SHARPNESS, TINT, CONTRAST+ and NOISE RED.


- SHARPNESS: alters the crispness of the image.
- TINT: alters the colour balance. There are 3 options: COLD (blue tint), NORMAL (balanced) or WARM (red tint).
- CONTRAST+: automatically adjusts the image contrast, according to content (the darkest part of the image is always black).
- NOISE RED: alleviates fuzziness (snowy picture). This setting is useful when reception is difficult.



Adjusting the sound

Press **HOME**. You can adjust: VOLUME and, for stereo models only, BALANCE, TREBLE, BASS and AVL.

- DELTA VOLUME (volume difference): allows you to compensate for the volume differences between the different programmes or the EXT sockets. This setting is available for programmes 1 - 40 and the EXT sockets.
- AVL (Automatic Volume Leveller): automatic volume control used to avoid sudden increases in volume, particularly when changing programme or during advertisements.




Storing settings

You can store your own sound and picture settings.

- 1 First carry out your menu settings.
- 2 Next, select PERSONAL and press **ENTER**. The message STORED is displayed. The settings are stored.


Values are saved under PERSONAL in the Smart sound and picture controls (**PERSONAL** and **PERSONAL**).

Note: volume and ?VOLUME are automatically stored and do not need to be stored in the PERSONAL menu.



Locking the set

This function (only available on certain models) allows you to lock the set in order to limit its use completely or partially.



Key lock

- 1 Press **HOME**, select TV LOCK (LOCK) and press **ENTER**.
 - 2 Set the LOCK to ON. The keys are locked.
 - 3 Switch off the set and put the remote control out of sight. The set cannot be used (it can only be switched on using the remote control).
- To cancel: switch LOCK to OFF.

Programme lock

- 1 Press **HOME**, select TV LOCK (LOCK) and press **ENTER**.
 - 2 Select PARENTAL CONT. and press **ENTER**.
 - 3 Enter your confidential access code. The first time, enter the code 0711 then confirm by re-entering 0711. The menu appears.
 - 4 Select PROGRAM NO. and use keys **0-9** or **0-9** to enter the number of the programme or socket you wish to lock.
- To lock all of them, select ALL.

- 5 Repeat stages 4 and 5 for each programme to be locked. You can lock 5 programmes separately.
- 6 Press **ENTER** to exit. To watch a programme which has been locked you will now need to enter the confidential code; otherwise the screen will remain blank.

When a locked programme is displayed, use the **0-9** keys to access other programmes (the **0-9** keys are used to enter the code). Caution: in the case of encrypted programmes which use an external decoder, it is necessary to lock the corresponding EXT socket (and not the programme number).


To unlock all programmes

- 1 Repeat stages 1 - 2 above, then:
- 2 Select CLEAR ALL and press **ENTER**. All programmes are unlocked.

To change the confidential code


- 1 Repeat stages 1 - 2 above, then:
 - 2 Select CHANGE CODE and enter your own 4-digit number.
 - 3 Confirm by entering it again. Your new code will be stored.
- If you have forgotten your confidential code, enter the universal code 0711 twice.

To exit: press **EXIT**.



Timer function

This function (only available on certain models) allows you to use your TV as an alarm clock.



Key lock

- 1 Press **HOME**, select TIMER (TIMER) and press **ENTER**.
 - 2 The SET CLOCK menu appears. Enter the time (0-9 or 0-9).
- Important: the time is updated automatically each time the set is switched on using teletext information taken from programme 1. If programme 1 does not have teletext, the update will not take place.


- 3 Select TIMER ACTIVE and press **ENTER** to switch the timer on or off.
- 4 Select PROGRAM NO. and enter the number of the programme required.
- 5 Select START TIME and enter the time at which the set is to switch on.
- 6 Press **ENTER** to put the set into standby mode. It will switch on automatically at the programmed time. If you leave the set switched on, it will merely change programmes at the set time.

The set switches off automatically after 4 hours if no further commands are given.

Teletext

Teletext is an information system, broadcast by certain channels, which can be read like a newspaper: it also provides subtitles for people with hearing difficulties or those who are unfamiliar with the language in which a particular programme is being broadcast (cable networks, satellite channels, etc.).

Press:



② Switch teletext on/off

①/③ Selecting a teletext page

④⑤⑥ Direct access to subject headings

⑦ *Temporary on/off

⑧ Page enlargement


⑨ Stop the sequence of sub-pages

⑩ Overlaying text on the TV picture

⑪ Reveal

⑫ *Table of contents

⑬ Favourite pages (available only on certain models)



To obtain:

To call up or exit from teletext. At first, the main index page appears with a list of the items available. Each page has a corresponding 3-figure number. If the selected channel does not broadcast teletext, 100 will appear and the screen will remain blank (in this case, exit from teletext and choose another channel).

Use keys ① to ③ or ①/③ to enter the page number required. For example, for page 120, press ① ② ③. The number is displayed in the top left-hand corner, the page counter starts searching and the page is displayed. Repeat the procedure to consult another page. If the counter continues searching, this means that the selected page is not broadcast. Choose another number.

Coloured zones are displayed at the bottom of the screen. The 4 coloured keys give access to the corresponding subjects or pages.

The coloured zones flash when the subject or the page is not yet available.

To switch teletext temporarily on or off.

Press this key to display the upper, then lower part of the screen, and then to return to the normal page size.

Some pages contain sub-pages which follow on automatically from one another. This key allows sub-page sequence to be enabled or disabled. The # sign appears in the top left hand corner.

To activate or deactivate screen overlay.

Use this key to reveal/conceal hidden information (answers to puzzles).

To return to the table of contents (normally page 100).

For teletext programmes 1 to 41, you can store 4 favourite pages which you can then access via the coloured keys ⑬.

① Press ⑬.
② Enter the number of the page required.
③ Press ⑬ then the coloured key ⑬ of your choice. The page is stored.
④ Repeat steps ② and ③ for the other coloured keys.

⑤ From now on, when you consult teletext, your favourite pages appear in colour at the bottom of the screen.

To get back to the normal subject headings, press ⑬.

To remove these settings, hold ⑬ down for 3 seconds.


* Only available with the remote control shown above.

Connecting other appliances

Depending on the model, the TV is equipped with 1 or 2 euroconnector sockets, EXT1 and EXT2. The EXT1 socket controls audio video input/output and RGB input. The EXT2 socket (if available) controls audio video input/output and S-VHS input.

Video recorder

Video recorder (only)
Connect as shown using a good quality euroconnector cable.
If your video recorder does not have a euroconnector socket, the only connection possible is via the aerial cable. You will therefore need to tune in your video recorder (test signal and assign it programme number 0 (see manual store, p. 4). To reproduce the video recorder picture, press ⑥.



Video recorder with decoder

Connect the decoder to the second euroconnector on the video recorder. You can then record scrambled transmissions.

Other equipment

Satellite receiver, decoder, DVD, games, etc.
For sets equipped with two euroconnector sockets, it is best to connect the equipment which produces RGB signals (digital decoder, DVD drives, games, etc.) to EXT1 and the equipment which produces S-VHS signals (S-VHS and Hi-8 video recorders) to EXT2.




Front panel connections

Depending on the model, sockets are on the front (sometimes under a flap) or on the right-hand side of the set.

Headphones

When the earphones are plugged in, the sound on the set is cut off. Adjust the volume using the ①/② keys. The headphones must have an impedance of between 32 and 600 ohms.



Camcorder


Certain models are equipped with AUDIOVIDEO connections. You will find 1 video input + 1 sound input (mono versions) or 2 sound inputs left (L) and right (R) on stereo versions. Make the connections, then use the ④ key to select EXT (or EXT2 for models with 2 euroconnector sockets). The switch between the front and rear sockets is automatic with priority on front sockets.

For a monophonic camera, connect the sound signal to the AUDIO L input. Use the ④ key to reproduce the sound through the left and right TV speakers.

To select connected equipment

Press ④ to select EXT(1) and, on models with 2 euroconnector sockets: EXT2 and Y/C2 (S-VHS signal on EXT2).

The switch is automatic on most appliances (decoders, etc.).




4. Mechanical instructions

4.1 Service positions

See figure 4.2 for the service position.
Disconnect the connecting cable feeding the right-hand and the left-hand speaker, also disconnect the degaussing cable.

The mono-carrier is removed by pushing the two centre clips at both chassis brackets outwards and pulling the panel forward.



CL 96532028_004.eps
190499

Figure 4-2

5. Service Modes, fault finding and repair tips

In this chapter the following paragraphs are included:

- 5.1 Test points
- 5.2 Service Modes and Dealer Service Tool (DST)
- 5.3 The menus and submenus
- 5.4 Error code buffer and error codes
- 5.5 The "blinking LED" procedure
- 5.6 Trouble shooting tips
- 5.7 Customer service mode (CSM)
- 5.8 ComPair
- 5.9 Ordering compare

5.1 Test points

The L9 chassis is equipped with test points in the service printing. These test points are referring to the functional blocks:

- A1-A2-A3, etc.: Test points for the AM Mono Demodulator (A9), ITT panel (D1) and Sound amplifier (D2)
- C1-C2-C3, etc.: Test points for the control circuit (A7) and the front control (A8)
- F1-F2-F3, etc.: Test points for the frame deflection circuit (A3)
- I1-I2-I3, etc.: Test points for the Tuner Video IF circuit (A5)
- L1-L2-L3, etc.: Test points for the Line deflection circuit (A2)
- P1-P2-P3, etc.: Test points for the power supply (A1)
- S1-S2-S3, etc.: Test points for the synchronisation circuit (A4)

- V1-V2-V3, etc.: Test points for the video processing circuit / CRT panel (A6) / CRT panel (B)

Measurements are performed under the following conditions:

- Video: colour bar signal;
- audio: 3kHz left, 1kHz right

5.2 Service modes and Dealer Service Tool (DST)

For easy installation and diagnosis the dealer service tool (DST) RC7150 can be used. When there is no picture (to access the error code buffer via the OSD), DST can enable the functionality of displaying the contents of the entire error code buffer via the blinking LED procedure, see also paragraph 5.5. The ordering number of the DST (RC7150) is 4822 218 21232.

5.2.1 Installation features for the dealer

The dealer can use the RC7150 for programming the TV-set with presets. 10 Different program tables can be programmed into the DST via a GFL TV-set (downloading from the GFL to the DST; see GFL service manuals) or by the DST-I (DST interface; ordering code 4822 218 21277). For explanation of the installation features of the DST, the directions for use of the DST are recommended (For the L9 chassis, download code X should be used).

5.2.2 Diagnose features for service

L9 sets can be put in two service modes via the RC7150. These are the Service Default Mode (SDM) and the Service Alignment Mode (SAM).

5.2.3 Service Default Mode (SDM)

The purpose of the SDM is:

- provide a situation with predefined settings to get the same measurements as in this manual
- override 5V protections in case of short circuiting pin 24 and pin25.0228 and pin 0224 at A7.
- start the blinking LED procedure
- Setting of options controls
- Inspect the error buffer

Entering the SDM:

- By transmitting the "DEFAULT" command with the RC7150 Dealer Service Tool (this works both while the set is in normal operation mode or in the SAM)
- Standard RC sequence 062596 followed by the key "MENU"
- By shorting test-point M25 and M24pin 0228 and 0224 on the mono-carrier (A7) while switching on the set. After switching on the set the short-circuit can be removed. (Caution!! Override of 5V protections).

Exit the SDM:

Switch the set to Standby or press EXIT on the DST (the error buffer is also cleared).

Note: When the mains power is switched off while the set is in SDM, the set will switch to SDM immediately when the mains is switched on again. (The error buffer will not be cleared).

The SDM sets the following pre-defined conditions:

- Pal/Secam sets: tuning at 475.25 PAL (For France select the L'-signal)
- Volume level is set to 25% (of the maximum volume level).
- Other picture and sound settings are set to 50%.

The following functions are "ignored" in SDM since they interfere with diagnosing/repairing a set. "Ignoring" means that the event that is triggered is not executed, the setting remains unchanged.

- (Sleep)Timer
- Blue mute
- Auto switch off
- Hotel or Hospitality Mode
- Child lock or Parental lock
- Skipping, blanking of "Not favourite" present/channels
- Automatic storing of Personal Preset settings
- Automatic user menu time-out

All other controls operate normally.

5.2.4 Special functions in SDM

Access to normal user menu

Pressing the "MENU" button on the remote control will enter the normal user menu (TV lock, Installation, Brightness, colour and contrast) while "SDM" remains displayed in top of screen). Pressing the "MENU" key again will return to the last SDM status.

Error buffer

Pressing the "OSD" button on the remote control shows all OSD (incl. error buffer).

Access to SAM

By pressing the "CHANNEL DOWN" and "VOLUME DOWN" buttons on the local keyboard simultaneously or pressing "ALIGN" on theDST DST, the set switches from SDM to SAM

In the SDM the following information is displayed on the screen:




Figure 5-3 Service Default Mode screens and structure

Explanation notes/references:

1. (1) "LLLL" Operation hours timer (hexadecimal)
2. (2) Software identification of the main micro controller (L90BBC X.Y)
 - L90 is the chassis name for L9
 - BBC is 2 letter and 1 digit combination to indicate the software type and the supported languages:
 - X = (main version number)
 - Y = (subversion number) BB = (range specification)
3. (3) "SDM" To indicate that the TV set is in the service default mode
4. (4) "OP" Options Code which exists of 2 characters. It is possible to change each option code
5. "VALUE" The value of the selected option (ON/OFF or a combination of 2 letters)
6. "XXX" Value of the options bytes (OB1 .. OB7)
7. "ERR" The last five detected errors; The left most number indicates the most recent error detected.

The MENU UP or MENU DOWN command can be used to select the next/previous option; The MENU LEFT and MENU RIGHT command can be used to change the option value. Remark: When the option-code RC = OFF, the P+ and the P- key have the same functions as the MENU UP/DOWN keys while the VOL+ and the VOL- key have the same function as the MENU LEFT/RIGHT keys. When the option RC = OFF it is not possible to change the channel preset or to adjust the volume when in SAM/SDM menu. Using a L9 remote control, option-code RC = ON, the P+, P-, VOL- and VOL+ can be used to change the preset and/or to adapt the volume, while the menu-cursor keys are used to select the option and to change its value.

For an extended overview of the option codes see Chapter 8 - Options

5.2.5 Service Alignment Mode (SAM)

The purpose of the SAM is to do tuning adjustments, align the white tone, adjust the picture geometry and do sound adjustments.

For recognition of the SAM, "SAM" is displayed at the top of the right side of the screen

Entering SAM:

- By transmittingpressing the "ALIGN" button command without the RC7150 Dealer Service Tool
- By pressing the "CHANNEL DOWN" and "VOLUME DOWN" key on the local keyboard simultaneously when the set is in SDM
- Standard RC sequence 062596 followed by the key "OSD"

- By shorting pin 0225 and 0226 on the mono-carrier (A7) while switching on the set. After switching on the set the short-circuit can be removed. (Caution!! Override of 5V protections).

Exit the SAM:

Switch the set to standby or press EXIT on the DST (the error buffer is cleared).

Note: When the mains power is switched off while the set is in SAM, the set will switch to SAM immediately when the mains is switched on again. (The error buffer will not be cleared).

In the SAM the following information is displayed on the screen:
Figure 5.2 Service Alignment Mode screens and structure

Access to normal user menu

Pressing the "MENU" button on the remote control will enter the normal user menu (TV lock, installation, brightness, colour and contrast) while "SAM" remains displayed in top of screen.

Pressing the "MENU" key again will return to the last SAM status.

Pressing the "OSD" button of the remote control shows only "SAM" in the top of screen

Access to SDM

Pressing the "DEFAULT" button on the DST

SAM menu control

Menu items (AKB, VSD, Tuner, White tone, Geometry and Audio) can be selected with the MENU Up or MENU DOWN key. Entry into the selected items (sub menus) is done by the MENU LEFT or MENU RIGHT key. The selected item will be highlighted.

With the cursor LEFT/RIGHT keys, it is possible to increase/decrease the value of the selected item.




Figure 5-4 Service Alignment Mode screens and structure

5.3 The menus and submenus

5.3.1 Tuner sub menu

The tuner sub menu contains the following items:

- IF_PLL : PLL Alignment for all PAL/SECAM systems, excluding SECAM-LL'
- IF_PLL POS : PLL Alignment for SECAM-LL'
- IF_PLL OFFSET : Default value = 48 ; Do not align
- AFW : AFC Window
- AGC : AGC take-over point
- YD : Default value = 12 ; Do not align
- CL : Default value = 4 ; Do not align
- AFA
- AFB

The items AFA and AFB can not be selected, they are for monitoring purposes only.

The commands MENU UP and MENU DOWN are used to select the next/previous item.

The commands MENU LEFT and MENU RIGHT are used to increase/decrease the value of the selected item. The changed values will be send directly to the related hardware.

The item values are stored in NVM if this sub menu is left.

5.3.2 White tone sub menu

The commands MENU UP and MENU DOWN are used to select the next/previous item.

The commands MENU LEFT and MENU RIGHT are used to increase/decrease the value of the selected item. The changed values will be send directly to the related hardware.

The item values are stored in NVM if this sub menu is left.

The white tone sub menu contains the following items:

- NORMAL RED
- NORMAL GREEN
- NORMAL BLUE
- DELTA COOL RED
- DELTA COOL GREEN
- DELTA COOL BLUE
- DELTA WARM RED
- DELTA WARM GREEN
- DELTA WARM BLUE

OSD is kept to a minimum in this menu, in order to make white tone alignment possible.

The Contrast Plus feature (black stretch) is set to OFF when the white tone submenu is entered.

5.3.3 Audio sub menu

The tuner sub menu contains the following items:

- A-FM : Default value = 232 ; Do not align
- AT : Default value = 4 ; Do not align
- STEREO : Default value = 15 ; Do not align
- DUAL : Default value = 12 ; Do not align

The sound adjustments sub menu are not available in Mono sets.

The presence of an item in the menu strongly depends on the selected soundboard (option SB).

5.3.4 Geometry sub menu

The geometry sub menu contains the following items:

- VAM : Vertical amplitude
- VSL : Vertical slope
- SBL : Service blanking
- HSH : Horizontal shift
- H60 : Default value = 10 ; Do not align
- V60 : Default value = 12 ; Do not align
- VSC : Vertical S correction
- VSH : Vertical shift

5.4 Error code buffer and error codes

5.4.1 Error code buffer

The error code buffer contains all errors detected since the last time the buffer was erased. The buffer is written from left to right.

- when an error occurs that is not yet in the error code buffer, the error is written at the left side and all other errors shift one position to the right
- the error code buffer will be cleared in the following cases:
 1. exiting SDM or SAM with the "Standby" command on the remote control
 2. transmitting the commands "EXIT" with the DST (RC7150)
 3. transmitting the commands "DIAGNOSE-9-9-OK" with the DST.
- The error buffer is not reset by leaving SDM or SAM with the mains error buffer is not switch.

Examples:

- ERROR: 0 0 0 0 0 : No errors detected
- ERROR: 6 0 0 0 0 : Error code 6 is the last and only detected error
- ERROR: 5 6 0 0 0 : Error code 6 was first detected and error code 5 is the last detected (newest) error

5.4.2 Error codes

In case of non-intermittent faults, clear the error buffer before starting the repair to prevent that "old" error codes are present. If possible check the entire content of the error buffers. In some situations an error code is only the RESULT of another error code (and not the actual cause).

Note: a fault in the protection detection circuitry can also lead to a protection.

- a. Error 0 = No error
- b. Error 1 = X-ray (Only for USA sets)
- c. Error 2 = High beam current protection
High beam protection active; set is switched to protection; error code 2 is placed in the error buffer; the LED will blink 2 times (repeatedly).
As the name implies, the cause of this protection is a too high beam current (bright screen with flyback lines). Check whether the +160V supply to the CRT panel is present. If the voltage is present, the most likely cause is the CRT panel or the picture tube. Disconnect the CRT panel to determine the cause. If the +160V voltage is not present, check R3416 and D6409 (Horizontal Deflection - A2)
EW protection:
If this protection is active, the cause could be one of the following items;
horizontal deflection coil 5445
S-correction capacitor 2407
flyback capacitor 2434
line output stage
short circuit of flyback diode 6434
EW power-transistor 7402 or driver-transistor 7400
- d. Error 3 = Vertical / Frame protection
There are no pulses detected at pin 37 of the main microprocessor 7600 (panel A7).
If this protection is active, the causes could be one of the following items;
IC 7460 is faulty (A3)
Open circuit of vertical deflection coil
Vlotaux +13V not present and/or Vlotaux -13V not present
Resistor 3463
Transistor 7609 is defect (A7)
- e. Error 4 = Sound processor (IC7803) I2C error (MSP3415D)
Sound processor does not respond to the micro controller
- f. Error 5 = Bimos (IC7250) start-up error (POR bit)

Bimos start-up register is corrupted or the I2C line to the Bimos is always low or no supply at pin 12 of the Bimos. This error is usually detected during start-up and hence will prevent the set from starting up.

- g. Error 6 = Bimos (TDA884x) I2C error
Note that this error may also be reported as a result of error codes 4 (in that case the Bimos might not be the actual problem)
- h. Error 7 = General I2C error. This will occur in the following cases:
SCL or SDA is shorted to ground
SCL is shorted to SDA
SDA or SCL connection at the micro controller is open circuit.
- i. Error 8 = Microprocessor (IC7600) internal RAM error (A7)
The micro controller internal RAM test indicated an error of the micro controller internal memory (tested during start-up);
- j. Error 9 = EEPROM Configuration error (Checksum error); EEPROM is corrupted.
- k. Error 10 = I2C error EEPROM . NV memory (EEPROM) does not respond to the micro controller
- l. Error 11 = I2C error PLL tuner. Tuner is corrupted or the I2C line to the Tuner is low or no supply voltage present at pin 9, pin 6 or pin 7 of the tuner.
- m. Error 12 = Black current loop instability protection. The black current could not be stabilised. The possible cause could be a defect in one or more of the RGB amplifiers, RGB guns or RGB driving signals.

5.5 The "blinking LED" procedure

The contents of the error buffer can also be made visible through the "blinking LED" procedure. This is especially useful when there is no picture. There are two methods:

- When the SDM is entered, the LED will blink the number of times, equal to the value of the last (newest) error code (repeatedly).
- With the DST all error codes in the error buffer can be made visible. Transmit the command: "DIAGNOSE x OK" where x is the position in the error buffer to be made visible x ranges from 1, (the last (actual) error) to 5 (the first error). The LED will operate in the same way as in point 1, but now for the error code on position x.

Example:

Error code position 1 2 3 4 5

Error buffer: 8 9 5 0 0

- after entering SDM: blink (8x) - pause - blink (8x) - etc.
- after transmitting "DIAGNOSE- 2- OK" with the DST blink (9x) - pause - blink (9x) - etc.
- after transmitting "DIAGNOSE- 3- OK" with the DST blink(5x) - pause - blink(5x) - etc.
- after transmitting "DIAGNOSE- 4- OK" with the DST nothing happens

5.6 TROUBLE SHOOTING TIPS

In this paragraph some trouble shooting tips for the deflection and power supply circuitry are described. For detailed diagnostics, check the fault finding tree or use COMPAIR.

5.6.1 THE DEFLECTION CIRCUIT:

1. Measure the +VBATT (95V) is present across 2551 (A2 - Line deflection). If the voltage is not present, disconnect coil 5551. (Horizontal deflection stage is disconnected). If the voltage is present then the problem might be caused by the deflection circuit. Possibilities:
 - Transistor 7402 is faulty

- The driver circuit around transistor 7400 is faulty
- No horizontal drive signal coming from the BIMOS 7250-D pin 40 (A4 - Synchronisation)
- Timer-IC 7607 or transistor 7608 is defect (A7 - Control)

2. Note: If the Collector of 7402 is shorted to the Emitter, hick-up noise can be heard from the power supply. In this case the E/W protection is disabled. is correctly working (a parabolic picture)
3. Also take note of protection circuits in the line output stage. If any of these circuits are activated, the set will shut down. Depending on the protection, the led will blink according to the fault defined. In order to determine which protection circuit is active, isolation of each separate circuit is necessary. These protection circuits are:
 - High beam current protection (LED blinks repetitively 2 times) - CRT panel (B)
 - Vertical protection (LED blinks repetitively 3 times) - Vertical deflection (A3)

5.6.2 THE POWER SUPPLY

To trouble shoot the L9 SMPS, first check the Vaux voltage on C2561. If this voltage is not present, check fuse F1572 and D6560. If F1572 or D6560 is not open circuit, the problem might be caused on the primary side of the switching supply. Check the output of the bridge rectifier on C2508 for approximately 300V DC at an input voltage of 230Vac. If this voltage is missing, check the bridge diodes 6502 .. 6505 and the fuse 1500. If fuse F1500 is found open, check MOSFET 7518 to make sure that there is no short circuit present and check R3518. If the 300V DC is present on C2508, check for a start-up voltage of approx. 13V on pin 1 of IC7520. If no start-up voltage is present, check if R3510 is open or zener 6510 is a short-circuit. It is necessary to have a feedback signal from the hot primary side of switch mode transformer T5545 at pin 1 and pin 2 for the power supply to oscillate. If the start-up voltage of 13V is present on pin 1 of IC7520 and the supply is not oscillating, check R3529 and D6540.

Check for a drive signal at the gate of MOSFET 7518, square wave signal - P1. Check pin 3 of IC7520 and R3525.

To determine whether OVP is active, check the presence of Vaux at C2561.

5.6.3 Customer Service Mode (CSM)

All L9 sets are equipped with the "Customer Service Mode" (CSM). CSM is a special service mode that can be activated and deactivated by the customer, upon request of the service technician/dealer during a telephone conversation in order to identify the status of the set. This CSM is a 'read only' mode, therefore modifications in this mode are not possible. Entering the Customer Service Mode. The Customer Service Mode can be switched on by pressing simultaneously the button (MUTE) on the remote control and any key on the control buttons (P+, P-, VOL +, VOL -) on the TV for at least 4 seconds.

When the CSM is activated:

- picture and sound settings are set to nominal levels
- "Service unfriendly modes" are ignored

Exit the Customer Service Mode.

The Customer Service Mode will switch off after:

- pressing any key on the remote control handset (except "P+" or "P-")
- switching off the TV set with the mains switch.

All settings that were changed at activation of CSM are set back to the initial values

5.6.4 The Customer Service Mode information screen

The following information is displayed on screen:

Text "CSM" on the first line

- Line number for every line (to make CSM language independent)
- Operating hours
- Software version L90BBC X.Y
- Text "CSM" on the first line
- Error buffer contents
- Option code information
- Configuration information
- Service unfriendly modes

```

1 HHHH L90BBC-X.Y          CSM
2 CODES xx xx xx xx xx
3 OP xxx xxx xxx xxx xxx xxx
4 SYS: xxxxxxxxxxxx
5 NOT TUNED
6 TIMER
7 LOCKED
8 (HOSPITAL) (HOTEL)
9 VOL LIM <value>

```

CL 86532104_014.aps
080299

Figure 5-5 Screen lay-out Customer Service Mode

SYS: xxxxxx = xxxxxx is the SYSTEM THAT IS SET FOR THIS PRESET

NOT TUNED = no ident signal present

TIMER = (SLEEP) TIMER is activated

LOCKED = Channel/preset locked via parental lock, child lock

HOTEL = HOTEL mode activated; HOSPITAL = HOSPITAL mode activated

VOL LIM = Volume limiter activated and set to the adjusted value

5.6.5 Exit

Any key (RC or local keyboard) except "channel up" / "channel down" (standby switched to standby, mains OFF switches set off, other keys switch to normal operation)

5.7 ComPair

5.7.1 Introduction

Compair (Computer Aided Repair) is a service tool for Philips Consumer Electronics products. ComPair is a further development on the DST service remote control allowing faster and more accurate diagnostics. ComPair has three big advantages:

- ComPair helps you to quickly get an understanding how to repair the L9.2E in short time by guiding you step by step through the repair procedures.
- ComPair allows very detailed diagnostics (on I2C level) and is therefore capable of accurately indicating problem areas. You do not have to know anything about I2C commands yourself; Compair takes care of this.
- ComPair speeds up the repair time since it can automatically communicate with the L9.2E (when the micro processor is working) and all repair information is directly available. When ComPair is installed together with the SearchMan L9.2E electronic manual, schematics and PCBs are only a mouse-click away.

ComPair consists of a Windows based fault finding program and an interface box between PC and the (defective) product. The ComPair interface box is connected to the PC via a serial or RS232 cable. In case of the L9.2E chassis, the ComPair interface box and the L9 communicate via an I2C cable (bi-directional) and via infra red communication (uni-directional; from ComPair interface box to L9.2E)

The ComPair fault finding program is able to determine the problem of the defective television. ComPair can gather diagnostic information in 2 ways:

1. Communication to the television (automatic)
2. Asking questions to you (manually)

ComPair combines this information with the repair information in its database to find out how to repair the L9.2E.

Automatic information gathering

Reading out the error buffer, ComPair can automatically read out the contents of the entire error buffer.

Diagnosis on I2C level. ComPair can access the I2C bus of the television. ComPair can send and receive I2C commands to the micro controller of the television. In this way it is possible for ComPair to communicate (read and write) to devices on the I2C busses of the L9.2E.

Manual information gathering

Automatic diagnosis is only possible if the micro controller of the television is working correctly and only to a certain extent. When this is not the case, ComPair will guide you through the fault finding tree by asking you questions and showing you examples. You can answer by clicking on a link (e.g. text or an waveform pictures) that will bring you to the next step in the faultfinding process.

A question could be: Do you see snow? (Click on the correct answer)

YES / NO

An example can be: Measure testpoint I7 and click on the correct oscillogram you see on the oscilloscope




Figure 5-6

By a combination of automatic diagnostics and an interactive question/answer procedure, ComPair will enable you to find most problems in a fast and effective way.

Additional features

Beside fault finding, ComPair provides some additional features like:

- Uploading/downloading of presets
- Managing of preset lists
- Emulation of the Dealer Service Tool

5.7.2 SearchMan (Electronic Service Manual)

If both ComPair and SearchMan are installed, all the Schematics and PCBs of the faulty set are available when clicking on the hyper-link of a schematic or a PCB in ComPair Example: Measure the DC-voltage on capacitor C2568 (Schematic/Panel) at the Monocarrier. Clicking on the PCB hyper-link, automatically shows the PCB with a high-lighted capacitor C2568. Clicking on the schematic hyper-link, automatically shows the position of a high-lighted capacitor at the schematic.

5.7.3 Connecting the ComPair interface

The ComPair Browser software should be installed and setup before connecting ComPair to the L9.2E. (See the ComPair Browser Quick Reference Card for installation instructions.)

1. Connect the RS232 interface cable to a free serial (COMM) port on the PC and the ComPair interface PC connector (connector marked with "PC").
2. Place the ComPair interface box straight in front of the television with the infrared window (marked "IR") directed to the television LED. The distance between ComPair interface and television should be between 0.3 and 0.6 meter. (Note: make sure that (also) in the service position, the ComPair interface infra red window is pointed to the standby LED of the television set (no objects should block the infra red beam))
3. Connect the mains adapter to the connector marked "POWER 9V DC" on the ComPair interface
4. Switch the ComPair interface OFF
5. Switch the television set OFF with the mains switch
6. Remove the rear cover of the television set
7. Connect the interface cable (4822 727 21641) to the connector on the rear side of the ComPair interface that is marked "I2C" (See Figure 5.8)
8. Connect the other end of the interface cable to the ComPair connector on the monocarrier (see figure 5.9)
9. Plug the mains adapter in the mains outlet and switch ON the interface. The green and red LEDs light up together. The red LED extinguishes after approx. 1 second (the green LED remains lit).
10. Start-up Compair and select "File" menu, "Open..."; select "L9.2E Fault finding" and click "OK"
11. Click on the icon (fig 5.7) to switch ON the communication mode (the red LED on the Compair interface wil light up)
12. Switch on the television set with the mains switch
13. When the set is in standby. Click on "Start-up in ComPair mode from standby" in the ComPair L9.2E fault finding tree, otherwise continue.



Figure 5-7




Figure 5-8

The set has now started up in ComPair mode. Follow the instruction in the L9.2E fault finding tree to diagnose the set. Note that the OSD works but that the actual user control is disabled

5.7.4 Preset installation

Presets can be installed in 2 ways with the L9.2E.

- Via infra red
 - only sending TO the television
 - the rearcover does NOT have to be removed
- Click on "File" "Open" and select "TV - use ComPair as DST" to use infra red
- Via cable
 - sending TO the television and reading FROM the television
 - the rearcover has to be removed

Click on "File" "Open" and select "L9.2E fault finding" to use the cable

Presets can be installed via menu "Tools", "Installation", "Presets".

5.8 Ordering ComPair

Compair order codes:

- Starterkit ComPair+SearchMan software + ComPair interface (excluding transformer): 4822 727 21629
- ComPair interface (excluding transformer): 4822 727 21631
- ComPair transformer (continental) Europe: 4822 727 21632
- ComPair transformer United Kingdom: 4822 727 21633
- Starterkit ComPair software: 4822 727 21634
- Starterkit SearchMan software: 4822 727 21635
- Starterkit ComPair+SearchMan software: 4822 727 21636
- Compair CD (update): 4822 727 21637
- SearchMan CD (update): 4822 727 21638
- ComPair interface cable (for L9): 4822 727 21641






Figure 5-9


6. Faultfinding trees, blockdiagram, supply diagram and testpoints.






Note 1

IRIS SYMPTOM CODE





Note 2:

(A1) means Drawing A1
 <P1> means Test point P1




6. Faultfinding trees, blockdiagram, supply diagram and testpoints.






Note 1:


IRIS SYMPTOM CODE





Note 2:

(A1) means Drawing A1
 <P1> means Test point P1











EF


Black current calibration















SUPPLY VOLTAGE DIAGRAM






IIC BUS INTERCONNECTION DIAGRAM












MAIN PANEL COMPONENT VIEW




CRT PANEL (COPPER TRACK VIEW)




ITT AUDIO PANEL (COPPER TRACK VIEW)














P1 $\text{\textcircled{1}}$ 300V DC
 P3 $\text{\textcircled{1}}$ 15V DC SDM
 P3 $\text{\textcircled{1}}$ 13V DC
 P4 $\text{\textcircled{1}}$ 9V5 DC SDM
 P4 $\text{\textcircled{1}}$ 95V DC
 P5 $\text{\textcircled{1}}$ 9V5 DC SDM
 P5 $\text{\textcircled{1}}$ 8V DC
 P6 $\text{\textcircled{1}}$ 17V DC SDM
 P6 $\text{\textcircled{1}}$ 15V DC
 L3 $\text{\textcircled{1}}$ 0V DC
 L4 $\text{\textcircled{1}}$ 13V DC
 L4 $\text{\textcircled{1}}$ 0V1 DC
 L5 $\text{\textcircled{1}}$ 8V DC
 L5 $\text{\textcircled{1}}$ 0V2 DC
 L6 $\text{\textcircled{1}}$ 8V DC
 L6 $\text{\textcircled{1}}$ 2V DC
 L7 $\text{\textcircled{1}}$ -13V DC
 L7 $\text{\textcircled{1}}$ -0V2 DC



A20 1V5 DC




→ = 0V



- F01 F9 6503 B5
- 0211 C2 6504 B5
- 0211A C2 6505 B6
- 0211B C2 6507 B6
- 0212 A2 6508 C6
- 0213 D2 6510 D4
- 0231 B2 6520 D6
- 0241 D11 6521 D6
- 0255 C11 6537 F7
- 1500 B3 6540 E7
- 1571 E10 6550 C10
- 1572 D10 6560 D9
- 1580 A8 6570 E10
- 2500 C3 6584 A9
- 2501 B3 6585 A8
- 2502 B5 6590 A10
- 2504 A3 7518 C6
- 2505 B5 7520 E2
- 2506 C3 7590 A9
- 2508 B6 7591 A9
- 2509 C7 9500 B2
- 2510 C7 9501 C2
- 2511 B7 9503 D5
- 2517 C6 9504 B3
- 2518 C7 9506 C5
- 2520 E2
- 2521 H4
- 2522 H3
- 2524 F6
- 2529 D4
- 2530 H4
- 2531 E2
- 2532 F2
- 2533 G2
- 2534 G2
- 2537 F7
- 2540 E6
- 2541 F7
- 2545 G8
- 2550 C10
- 2560 C9
- 2565 C10
- 2570 E10
- 2571 F10
- 2572 F9
- 2586 A10
- 2590 E7
- 3501 B3
- 3502 C2
- 3503 A4
- 3504 A3
- 3505 B4
- 3506 B5
- 3509 B7
- 3510 C4
- 3512 H2
- 3513 H3
- 3517 C6
- 3518 D7
- 3519 D7
- 3520 E2
- 3521 D6
- 3524 E2
- 3525 C6
- 3528 E6
- 3529 D4
- 3530 D4
- 3532 F2
- 3534 G2
- 3536 F2
- 3537 D3
- 3538 F7
- 3539 F6
- 3540 F6
- 3541 E7
- 3542 C2
- 3547 C5
- 3548 C5
- 3570 F9
- 3595 A10
- 3596 A10
- 3597 A10
- 3598 A9
- 4510 D10
- 5500 C4
- 5501 B4
- 5502 E6
- 5516 C7
- 5521 H3
- 5540 E7
- 5545 B8
- 5550 C10
- 5552 D5
- 5570 E9
- 5571 E11
- 5572 E9
- 5573 C9
- 6500 B4
- 6501 B3
- 6502 B6

*	AUDIO O/P
5570	2W/3W
5572	1W

HOT GROUND
 ...V... Normal Operation
 (...V...) StandBy Operation




DIVERSITY LIST FOR A1

ITEM NO.	FR20/21 AP/LA	HR20/21 EU	LR20/21 US	LR14 US	HR14 EU	HR20/21 AP	HR14 AP	FR20/21 US	FR14 US	FR20/21 INDIA	FR14 INDIA	FR14 INDO	FR20 INDO	Lf US(m)
5500	DMF 2820F	-	DMF 2820F	DMF 2820F	-	-	-	DMF 2820F	DMF 2820F	DMF 2820F	DMF 2820F	DMF 2820F	DMF 2820F	1 2
5501	-	DMF 2430F	-	-	DMF 2430F	DMF 2430F	DMF 2430F	-	-	-	-	-	-	
3504	PTC 9R	PTC 9R	-	-	PTC 9R	PTC 9R	PTC 9R	-	-	PTC 9R	PTC 9R	PTC 9R	PTC 9R	
3503	-	-	ZPB 10R	ZPB 10R	-	-	-	ZPB 9R	ZPB 9R	-	-	-	-	ZF
3506	2R2	2R2	2R2	2R2	2R2	2R2	2R2	2R2	2R2	2R2	2R2	-	-	
3547	-	-	-	-	-	-	-	-	-	-	-	NTC 10R	NTC 4R7	
3548	-	-	-	-	-	-	-	-	-	-	-	-	NTC 4R7	
9506	-	-	-	-	-	-	-	-	-	-	-	JUMPER	-	
3538	82K	100K	100K	100K	100K	82K	82K	100K	82K	82K	82K	82K	82K	
3539	15K	18K	18K	18K	18K	15K	15K	18K	18K	15K	15K	15K	15K	
5552	-	-	-	-	-	-	-	-	-	-	-	-	-	
7518	6NA60FI	6NA60FI	6NA60FI	6NA60FI	4NA60FI	6NA60FI	4NA60FI	6NA60FI	6NA60FI	6NA60FI	6NA60FI	6NA60FI	6NA60FI	6N
2508	220u/400	100u/400	220u/200	220u/200	100u/400	100u/400	100u/400	220u/400	220u/400	220u/450	220u/450	100u/400	220u/400	22
2518	220p	220p	470p	470p	220p	330p	330p	220p	220p	330p	330p	330p	330p	
2509	820p	820p	1n	1n	1n	820p	820p	820p	1n	820p	820p	820p	820p	
2510	820p	820p	1n	1n	1n	820p	820p	820p	1n	820p	820p	820p	820p	
3518	OR27	OR33	OR33	OR33	OR33	OR33	OR33	OR27	OR27	OR27	OR27	OR27	OR27	C
2510	-	-	IN5602	IN5602	-	-	-	IN5602	IN5602	-	-	-	-	IF
3518	-	-	IN5602	IN5602	-	-	-	IN5602	IN5602	-	-	-	-	IF
5545	DASUNG	ELDOR	ELDOR	ELDOR	ELDOR	DASUNG	DASUNG	ELDOR	ELDOR	DASUNG	DASUNG	DASUNG	DASUNG	E
113	BLACK H.SINK	BLACK H.SINK	WHITE H.SINK	WHITE H.SINK	WHITE H.SINK	BLACK H.SINK	WHITE H.SINK	BLACK H.SINK	BLACK H.SINK	BLACK H.SINK	BLACK H.SINK	BLACK H.SINK	BLACK H.SINK	V H
2550	680p	1n	1n	1n	1n	680p	680p	1n	1n	680p	680p	680p	680p	
3528	150E	220E	150E	150E	270E	150E	150E	270E	150E	150E	150E	150E	150E	
3536	27K	27K	27K	27K	27K	47K	27K	27K	39K	27K	27K	27K	27K	
5521	2u2	2u2	2u2	2u2	2u2	2u2	2u2	3u3	2u2	2u2	2u2	2u2	2u2	
2522	4n7	4n7	4n7	3n3	5n6	4n7	3n3	4n7	3n3	4n7	3n3	3n3	3n3	
2521	4n7	4n7	4n7	3n3	5n6	4n7	3n3	4n7	3n3	4n7	3n3	3n3	3n3	
2586	-	-	220u/25	220u/25	-	-	-	220u/25	220u/25	-	-	-	-	
1580	-	-	RELAY G5P-1A	RELAY G5P-1A	-	-	-	RELAY G5P-1A	RELAY G5P-1A	-	-	-	-	
6585	-	-	BAS216	BAS216	-	-	-	BAS216	BAS216	-	-	-	-	
6584	-	-	BAS216	BAS216	-	-	-	BAS216	BAS216	-	-	-	-	
6590	-	-	BAS216	BAS216	-	-	-	BAS216	BAS216	-	-	-	-	
7591	-	-	BC847B	BC847B	-	-	-	BC847B	BC847B	-	-	-	-	
7590	-	-	BC847B	BC847B	-	-	-	BC847B	BC847B	-	-	-	-	
3598	-	-	22K	22K	-	-	-	22K	22K	-	-	-	-	
3597	-	-	10K	10K	-	-	-	10K	10K	-	-	-	-	
3596	-	-	10K	10K	-	-	-	10K	10K	-	-	-	-	
3595	-	-	68K	68K	-	-	-	68K	68K	-	-	-	-	
9504	JUMPER	JUMPER	-	-	JUMPER	JUMPER	JUMPER	-	-	JUMPER	JUMPER	JUMPER	JUMPER	JL
9500	-	-	JUMPER	JUMPER	-	-	-	JUMPER	JUMPER	-	-	-	-	JL
9501	-	-	JUMPER	JUMPER	-	-	-	JUMPER	JUMPER	-	-	-	-	JL

HR21 CHINA	FR14 AP/LA
-	DMF 2820F
DMF 2430F	-
PTC 9R	PTC 9R
-	-
2R2	2R2
-	-
-	-
-	-
82K	82K
15K	15K
-	JUMPER
6NA60FI	6NA60FI
100u/450	220u/400
330p	330p
820p	820p
820p	820p
OR33	OR27
-	-
-	-
DASUNG	DASUNG
BLACK H.SINK	BLACK H.SINK
680p	680p
150E	150E
27K	27K
2u2	2u2
4n7	3n3
4n7	3n3
-	-
-	-
-	-
-	-
-	-
-	-
-	-
-	-
-	-
JUMPER	JUMPER
-	-
-	-

1 2 3 4 5 6 7

A2 LINE DEFLECTION




Europe	14"	20"	21"
2407	9.1nF	11nF	11nF
2411	1uF	1uF	100uF
2416	NA	560pF	NA
2434	NA	NA	NA
3411	1R	1R	1R
3414	1K8	Jumper	Jumper
3415	12K	10K	10K
5401	NA	100uH	NA
5404	56uH	NA	56uH
5406	NA	NA	Linearity Drum
5408	27uH	27uH	27uH
6434	Jumper	Jumper	Jumper
9402	NA	NA	NA
9408	NA	Yes	NA
9424	NA	NA	NA
9425	Yes	NA	NA

USA	14"	20"	21"
2407	8.2nF	10nF	9.1nF
2411	100uF	100uF	100uF
2416	680pF	560pF	330pF
2434	NA	NA	NA
3411	1R	1R	2R2
3414	2K7	1K8	2K2
3415	12K	10K	10K
5401	NA	NA	NA
5404	56uH	27uH	56uH
5406	NA	NA	Linearity Drum
5408	15uH	15uH	22uH
6434	Jumper	Jumper	Jumper
9402	NA	NA	NA
9408	NA	NA	NA
9424	NA	NA	NA
9425	Yes	Yes	NA


BRAZIL	14"	20"	21"
2407	8.2nF	10nF	11nF
2411	100uF	100uF	100uF
2416	680pF	680pF	330pF
2434	NA	NA	NA
3411	1R	1R	2R2
3414	1K	1K8	2K2
3415	15K	10K	10K
5401	NA	NA	NA
5404	56 uH	56uH	NA
5406	NA	NA	Linearity Drum
5408	15uH	15uH	22uH
6434	Jumper	Jumper	Jumper
9402	NA	NA	NA
9408	NA	NA	NA
9424	NA	NA	Yes
9425	Yes	Yes	NA

AP	14"	20"	21"
2407	9.1nF	11nF	10nF
2411	100uF	100uF	100uF
2416	680pF	680pF	330pF
2434	NA	NA	NA
3411	1R	1R	2R2
3414	1K	1K8	2K2
3415	15K	10K	10K
5401	NA	100uH	NA
5404	56 uH	NA	NA
5406	NA	NA	Linearity Drum
5408	15uH	15uH	22uH
6434	Jumper	Jumper	Jumper
9402	NA	NA	NA
9408	NA	NA	NA
9424	NA	NA	Yes
9425	Yes	NA	NA


CHINA	21"
2407	11nF
2411	100uF
2416	NA
2434	NA
3411	2R2
3414	2K2
3415	10K
5401	NA
5404	56uH
5406	Linearity Drum
5408	22uH
6434	Jumper
9402	NA
9408	NA
9424	NA
9425	NA



1 2 3 4 5 6 7




- 0220 F7
- 0221 B6
- 0221A A6
- 0221B A6
- 0221C A6
- 1400 D10
- 2400 D4
- 2401 D4
- 2402 E4
- 2403 E5
- 2404 B5
- 2405 D5
- 2406 E4
- 2407 D6
- 2408 C7
- 2409 C6
- 2410 C10
- 2411 F9
- 2412 C8
- 2413 A8
- 2414 D10
- 2415 E10
- 2416 D5
- 2417 E10
- 2418 B9
- 2420 B5
- 2431 C3
- 2432 D2
- 2434 C6
- 2551 B4
- 3400 D4
- 3402 D5
- 3403 E5
- 3404 D3
- 3405 B5
- 3406 B5
- 3407 B5
- 3411 D10
- 3412 F9
- 3414 B8
- 3415 B8
- 3416 A8
- 3417 D10
- 3418 F10
- 3419 F10
- 3420 E4
- 3421 E3
- 3423 B9
- 3424 B10
- 3425 C10
- 3426 F10
- 3427 F10
- 3428 F11
- 3431 C4
- 3432 D4
- 3433 C4
- 3434 C3
- 3435 C3
- 3436 E5
- 3440 F9
- 3441 F10
- 3474 C6
- 4401 B9
- 4435 C3
- 5401 B4
- 5404 B5
- 5406 B5
- 5408 B6
- 5410 E3
- 5444 D4
- 5445 B7
- 5551 B4
- 6400 D3
- 6401 E3
- 6402 C9
- 6403 F9
- 6404 D6
- 6405 E9
- 6406 F8
- 6408 G10
- 6409 A7
- 6410 D9
- 6412 D9
- 6413 B9
- 6414 B9
- 6415 E9
- 6418 E6
- 6419 E6
- 6431 C4
- 6432 C3
- 6433 B5
- 6434 C6
- 6435 C3
- 7400 E4
- 7401 B10
- 7402 D5
- 7403 F10
- 7404 F11
- 7431 C2
- 9402 B5
- 9403 C10
- 9404 E10
- 9408 C6
- 9424 B5
- 9425 B4




A4 SYNCHRONISATION

TDA 8844, 8845

- 2231 C3
- 2232 C4
- 2233 C2
- 2234 C3
- 2235 D5
- 2236 C5
- 2237 D2
- 2238 E2
- 2239 E2
- 2240 D4
- 2241 D4
- 2242 D5
- 2243 E4
- 2244 C4
- 2255 C5
- 3265 B4
- 3266 C2
- 3268 D2
- 3269 D3
- 3270 E3
- 3271 E2
- 3272 E5
- 3273 E5
- 3274 E4
- 3275 E5
- 3276 E4
- 5205 B4
- 5405 B5
- 7250-D C3




	Mono	Stereo
2235	1nF	-
2242	1nF	-




1 2 3 4 5 6

A5 TUNER, VIDEO IF, VIDEO DET, FM-AUDIO DET. TDA8844





1 2 3 4 5 6



- F02 C3
- 0239 A11
- 0240 A9
- 1000 B2
- 1001 A7
- 1002 B7
- 1003 E4
- 1005 G4
- 1010 D2
- 1011 C2
- 1012 C2
- 1200 E9
- 1201 E9
- 2001 B4
- 2002 C4
- 2003 B4
- 2004 C5
- 2005 B5
- 2006 B8
- 2008 A3
- 2012 E3
- 2200 F5
- 2201 F5
- 2202 F5
- 2203 F6
- 2205 F6
- 2206 D7
- 2207 D7
- 2208 G5
- 2209 G6
- 2220 D7
- 2227 E5
- 2252 B4
- 2256 E8
- 3000 C2
- 3001 C2
- 3002 A3
- 3003 A3
- 3013 C4
- 3014 B4
- 3015 C4
- 3016 C5
- 3017 A6
- 3018 B6
- 3020 B6
- 3021 B8
- 3027 E3
- 3028 E3
- 3029 E2
- 3030 E3
- 3031 F1
- 3032 F2
- 3033 F2
- 3034 F2
- 3200 F6
- 3201 F6
- 3202 F7
- 3204 D7
- 3205 E7
- 3206 F7
- 3207 D7
- 3208 E8
- 3209 F8
- 3212 E9
- 3213 F9
- 3216 D9
- 3226 G5
- 3227 G5
- 3229 G6
- 3277 E5
- 3278 E5
- 4000 D3
- 4001 E3
- 4200 G6
- 4201 F5
- 4210 D8
- 4215 C8
- 4218 F4
- 4221 D8
- 4222 E8
- 4223 E8
- 4247 E4
- 4248 F4
- 4249 E2
- 5004 C3
- 5202 D9
- 6003 C4
- 6004 C4
- 6005 B6
- 6006 B6
- 6007 A3
- 6008 E2
- 6009 E2
- 6216 A7
- 7000 B7
- 7001 F2
- 7002 F2
- 7010 A4
- 7250-A E6
- 7254 G5
- 7266 E7


SEE DIVERSITY LIST FOR A5





- F02 C3
- 0239 A12
- 0240 A10
- 1000 B2
- 1003 E4
- 1010 D2
- 1011 C2
- 1012 C2
- 1200 E9
- 1201 E9
- 1204 G4
- 2001 B4
- 2002 C4
- 2003 B5
- 2004 C5
- 2008 A4
- 2012 E4
- 2014 D6
- 2201 F6
- 2205 F7
- 2206 D7
- 2207 D7
- 2220 D8
- 2227 E5
- 2245 D7
- 3000 C2
- 3001 C2
- 3002 A3
- 3003 A4
- 3013 C5
- 3014 B5
- 3015 C5
- 3016 C5
- 3027 E3
- 3028 E3
- 3029 E2
- 3030 E3
- 3031 F2
- 3032 F3
- 3201 F7
- 3204 D8
- 3205 E7
- 3206 F8
- 3207 D7
- 3208 E8
- 3212 E10
- 3213 F10
- 3216 D10
- 3217 F8
- 3277 E5
- 3278 E5
- 4000 D4
- 4202 F5
- 4247 E4
- 5004 C4
- 5006 D6
- 5202 D9
- 5204 G6
- 6003 C5
- 6004 C5
- 6007 A4
- 6008 E2
- 6009 E3
- 6216 A8
- 7001 F2
- 7002 F3
- 7010 A5
- 7250-A E
- 7266 E8

*# SEE DIVERSITY LIST FOR A5



DIVERSITY TABLE FOR A5

TUNER VIDEO IF (Europe)

.	LL'ST	LLMN	B/G, D/K SW	BG	I
1003	K3953M	G1965M	-	G1984M	J1980M
1005	-	-	K6289K	-	-
1200	TPT02	TPT02	TPWA04	TPWA04	6MHZTPS
1201	-	6MHZTPS	6.5MHZTPS	-	-
2012	10 n	10 n	Jumper	-	-
2014	5p6	-	-	-	-
2201	2u2	2u2	1u	1u	1u
3013	10k	10k	Jumper	Jumper	Jumper
3027	6k8	6k8	6k8	-	-
3028	2k2	2k2	2k2	-	-
3029	2k2	2k2	2k2	-	-
3030	2k2	2k2	-	-	-
3031	4k7	4k7	4k7	-	-
3032	22k	22k	-	-	-
3202	-	-	1M5	1M5	1M5
4000	Jumper	Jumper	10n	Jumper	Jumper
4247	Jumper	Jumper	-	Jumper	Jumper
4248	-	-	Jumper	-	-
4249	-	-	Jumper	-	-
5004	0u22	0u82	0u82	0u82	0u82
5006	78MHzVCO	-	-	-	-
5202	3u3	3u9	3u9	6u8	6u8
6003	Bas216	Bas216	-	-	-
6004	Bas216	Bas216	-	-	-
6008	BA792	BA792	BA792	-	-
6009	BA792	BA792	-	-	-
7001	BC847B	BC847B	BC847B	-	-
7002	BC847B	BC847B	-	-	-
9207	Jumper	Jumper	-	Jumper	Jumper

TUNER SOUND IF (Europe)

#	Mono				Stereo	
	BG	I	BG/DK	BG/LL'	BG/I/DK	BG/I/LL'
0239	-	-	-	-	Yes	Yes
0240	-	-	-	-	Yes	Yes
1001	5.5	6.0	5.5	5.5	-	-
1002	-	-	6.5	6.0	-	-
1204	-	-	-	-	-	K9456M
2005	100p	100p	100p	100p	-	-
2006	82p	82p	82p	82p	-	-
2202	3n9	3n9	3n9	3n9	-	-
2203	10u	10u	10u	10u	-	-
2208	220n	220n	220n	220n	-	-
2209	Jumper	Jumper	Jumper	Jumper	-	-
2227	470n	470n	470n	470n	Jumper	Jumper
2245	-	-	-	-	-	4u7
3017	-	-	4k7	4k7	-	-
3018	-	-	2k2	2k2	-	-
3020	-	-	22k	22k	-	-
3200	680R	680R	680R	680R	-	-
3226	330k	330k	330k	330k	-	-
3227	680R	680R	680R	680R	-	-
3229	270R	270R	270R	270R	-	-
4202	-	-	-	-	-	Jumper
4218	Jumper	Jumper	Jumper	-	-	-
4221	-	-	-	-	Jumper	-
4223	Jumper	Jumper	Jumper	Jumper	Jumper	-
4283	Jumper	Jumper	Jumper	Jumper	Jumper	-
4284	Jumper	Jumper	Jumper	Jumper	Jumper	-
5204	-	-	-	-	-	1u8
6005	-	-	1N4148	1N4148	-	-
6006	-	-	1N4148	1N4148	-	-
7000	-	-	BC847B	BC847B	-	-
7254	BC847C	BC847C	BC847C	BC847C	-	-
9000	Jumper	Jumper	-	-	-	-
9203	Jumper	Jumper	Jumper	-	-	-
9204	-	-	-	Jumper	-	-
9205	-	-	-	Jumper	-	-
9220	-	-	-	Jumper	-	-
9253	Jumper	Jumper	Jumper	-	Jumper	Jumper


A8 FRONT CONTROL

0259 E3
 1680 B5
 1681 B5
 1682 B4
 1683 B4
 1684 B3
 2680 E4
 2697 B4
 3680 C3
 3681 D3
 3682 B3
 3683 B3
 3684 E3
 4600 E5
 6680 C3
 7680 D4

A
B
C
D
E
F
G
H


1 2 3 4 5 6

A
B
C
D
E
F
G
H



For Engg purpose only
 4600

For ITV only
 0259




1 2 3 4 5 6

1 2 3 4 5 6 7

A6 VIDEO PROCESSING (EUROPE)


TDA 8844, 8845




DIVERSITY TABLE

	SC1 (Mono)	SC1 (Mono) Front Cinch (Mono)	SC1, SC2 (Stereo)	SC1 (Stereo) Front Cinch (Stereo)	SC1, SC2 (Stereo) Side AV (Stereo)
2212	-	-	1nF	-	1nF
2213	-	100nF	100nF	-	100nF
3224	-	75R	75R	-	75R
3228	-	100R	100R	-	100R





	LL'ST	LLMN	PAL/SECAM NTSC	PAL NTSC	PAL W/O NTSC	PAL/SECAM W/O NTSC
1208	3.58MhzXII	3.58MhzXII	3.58MhzXII	3.58MhzXII	-	-
2211	100nF	470nF	100nF	470nF	470nF	470nF
2248	15pF	15pF	15pF	15pF	-	-
3206	270R	270R	150R	270R	270R	150R
3208	68R	68R	82R	82R	82R	82R
3213	470R	560R	82R	470R	560R	560R
3217	6K8	-	-	-	-	-
7250	TDA8845N1	TDA8842S1	TDA8842S1	TDA8841S1	TDA8841S1	TDA8842S1



1 2 3 4 5 6 7




- 0243 B12
- 1205 D4
- 1208 D5
- 2210 C2
- 2211 C2
- 2212 B4
- 2213 B4
- 2214 D2
- 2215 D3
- 2216 D3
- 2217 D4
- 2218 E12
- 2221 D6
- 2222 D5
- 2223 D8
- 2224 E8
- 2225 E8
- 2226 G9
- 2228 E11
- 2229 E11
- 2230 E11
- 2248 D4
- 2250 C11
- 3214 E11
- 3218 C2
- 3219 C2
- 3223 C2
- 3224 B4
- 3225 D6
- 3228 B4
- 3233 E8
- 3234 E8
- 3235 E8
- 3236 F8
- 3237 F8
- 3243 G9
- 3246 F10
- 3247 B8
- 3248 B8
- 3257 B10
- 3258 C10
- 3259 C10
- 3260 C10
- 4206 F9
- 4237 F8
- 5260 B11
- 6211 F9
- 6212 E9
- 6213 D11
- 6214 D11
- 6215 D11
- 7250-B C3
- 7250-C B10
- 7256 B3




1 2 3 4 5 6 7


A7 CONTROL



1 2 3 4 5 6 7




0219 A12	3645 B8
0224 A10	3646 B8
0225 F3	3647 G8
0226 F3	3648 F8
0228 A10	3649 F8
0236 D12	3650 E2
0237 E12	3651 F2
0238 C12	3652 E2
0256 F12	3653 F3
0267 G12	3654 E3
0605 D6	3655 E4
1600 D8	3670 A6
2600 B2	4614 C6
2601 C3	4615 D5
2604 A7	4616 B2
2605 A7	5601 A7
2606 B7	5602 A7
2607 E3	5603 A9
2608 G2	5604 E8
2609 F5	5605 B7
2610 G2	6600 B2
2611 F6	6601 C2
2612 A11	6602 E10
2613 B10	6603 F10
2614 B10	6604 F10
2615 D9	6605 G10
2616 D8	6610 E2
2617 D8	6612 E3
2618 E10	6669 D2
2619 D8	7600 B6
2620 E9	7601 A10
2621 F9	7602 A2
2622 F9	7605 D3
2623 G9	7607 G2
2624 G6	7608 G4
2625 G5	7609 D9
2626 E10	7610 E9
2651 F2	7611 D3
2670 B5	7612 B2
2675 D2	7620 E2
3600 B2	7621 E3
3601 B1	9618 G8
3602 C2	9619 G8
3603 C2	9620 F8
3605 D2	9652 E10
3606 D2	9653 F10
3607 C3	9654 F10
3608 F5	9655 G10
3609 F2	
3610 G2	
3611 G2	
3612 G4	
3613 H4	
3614 H4	
3615 H3	
3616-A A5	
3616-B A5	
3616-C B5	
3616-D B5	
3616-E B5	
3616-H B5	
3616-I C5	
3616-J C5	
3616-K C5	
3617-A F5	
3617-B F5	
3617-C E5	
3617-D E5	
3617-E E5	
3617-F E5	
3618 F5	
3619 G5	
3620 G6	
3622 B8	
3623 B8	
3624-A A9	
3624-B A9	
3624-C B9	
3624-D B9	
3624-E B9	
3624-F C9	
3624-G C9	
3625 A10	
3626 A10	
3627 A10	
3628 C9	
3629 D9	
3630 D10	
3631 E10	
3632 E9	
3633 E10	
3634 E9	
3635 C5	
3636 E3	
3637 B6	
3639 E9	
3640 F9	
3641 F9	
3642 G9	
3643 F8	
3644 F7	



1 2 3 4 5 6 7

A9 AM MONO DEMODULATOR

(for BG//LL Mono sets only)



1 2 3 4 5 6 7

8

9

10

11

12

1701 D4
 2702 E5
 2703 E6
 2704 E7
 2705 F7
 2706 E7
 2707 E9
 2709 C7
 2710 C7
 3707 E8
 3709 F7
 3710 F8
 3712 E9
 3713 E9
 4220 E8
 7703 E8
 7704 E9
 7705 C5

A

B

C


D

E

F

G

H



A1

10mV / div AC
 5µs / div

8

9


10

11

12

1 2 3 4 5 6 7

A 1 Ø SMART SOUND + MONO SOUND AMPLIFIER




Sound Control		
	Smart Sound	Basic Sound
2972	33nF	-
2973	100nF	-
2974	82nF	-
2975	10nF	-
3973	470R	-
3974	6K8	Jumper
3975	5K6	-
3976	1K8	-
3977	1K8	-
3978	12K	-
3979	220R	-
7952	BC847B	-
7955	BC847B	-


Sound Amplifier		
*	1W	2W/3W/4W
2952	-	2n2
2954	-	220nF
2956	2n2	-
2957	220nF	-
7953	-	TDA7052B
7954	TDA7056B	-

	BassSw	TrebleSw
ON	L	L
OFF	H	H

1 2 3 4 5 6 7




- 0215 C10
- 0215A B11
- 0215B B11
- 0264 D4
- 2950 E5
- 2951 E7
- 2952 C7
- 2953 B6
- 2954 B8
- 2955 E3
- 2956 D7
- 2957 D9
- 2958 C10
- 2959 C10
- 2971 B4
- 2972 B5
- 2973 C5
- 2974 C6
- 2975 C6
- 2976 B6
- 3950 E5
- 3953 E7
- 3971 B3
- 3972 C3
- 3973 B5
- 3974 B5
- 3975 C5
- 3976 C5
- 3977 C5
- 3978 C5
- 3979 D6
- 3980 B3
- 3981 C3
- 3982 C5
- 3983 B5
- 4905 D6
- 4906 B3
- 4907 B4
- 4908 B5
- 6953 E6
- 7951 B3
- 7952 C4
- 7953 B7
- 7954 D7
- 7955 D5
- 7956 E6
- 9953 E5
- 9958 F3



1 2 3 4 5 6 7

A 11 FRONT CINCH + HEADPHONE



NOTE : 0191 use 242202604471 for INDIA only
for other regions use 242202604747

1 2 3 4 5 6 7

8

9

10

11

12

0217 E6
 0218-A C2
 0218-B B2
 0218-C D2
 0230 C5
 0232 E4
 0234 F6
 0249 B5
 1150 E3
 1151 F3
 1152 D3
 1153 B3
 1154 C3
 2171 B4
 2172 C4
 2173 E3
 2174 E3
 2176 F3
 2177 F3
 3150 B3
 3151 A3
 3152 C3
 3153 B3
 3155 D4
 3156 E3
 3157 F3
 3158 E2
 3159 E2
 4150 F5
 4151 A3
 4152 B2
 4153 B3
 4154 F2
 4156 D3
 6161 D4

A

B

C

D

E

F

G

H

Front I/O Configuration

	SC1 Mono	SC1,Front Cinch Mono	SC1,SC2 Stereo	SC1,Front Cinch Stereo	SC1,SC2,Side AV Stereo
0218	-	B,C	-	A,B,C	-
0230	-	Yes	-	Yes	-
0249	-	Yes	Yes	Yes	-
2171	-	-	-	330pF	-
2172	-	330pF	-	330pF	-
3150	-	-	-	47K	-
3151	-	-	-	1K	-
3152	-	47K	-	47K	-
3153	-	1K	-	1K	-
3155	-	-	-	-	-
4151	-	-	Yes	-	-
4152	-	Yes	-	-	-
4153	-	Yes	Yes	-	-
4155	-	Yes	-	-	-
4156	-	-	-	Yes	-
6161	-	-	-	-	-

Headphone Configuration

	Headphone Stereo	Headphone Stereo
0232	Yes	Yes
0234	Yes	-
2173	330pF	330pF
2174	10uF	10uF
2176	330pF	330pF
2177	10uF	10uF
3156	270R	270R
3157	270R	270R
4154	-	Yes

8

9


10

11


12

1 2 3 4 5 6 7

B CRT PANEL



1 2 3 4 5 6 7




- VG2 F10
- 0165 B8
- 0244 G3
- 0245 C2
- 0254 D8
- 1300 B8
- 2313 F4
- 2323 D4
- 2331 B4
- 2341 F6
- 2342 H3
- 2343 H4
- 3311 F3
- 3312 F4
- 3313 F4
- 3314 E4
- 3316 D5
- 3317 C6
- 3321 D3
- 3322 D4
- 3323 E4
- 3324 C4
- 3326 C5
- 3327 C6
- 3331 C3
- 3332 C4
- 3333 C4
- 3334 B4
- 3336 A5
- 3337 B7
- 3341 E6
- 3347 F5
- 3348 E6
- 3349 F7
- 3350 F7
- 5341 G3
- 5342 H3
- 6311 E5
- 6321 C5
- 6331 B5
- 6341 A5
- 6342 G4
- 6343 G6
- 7311 F4
- 7312 E5
- 7313 E5
- 7321 D4
- 7322 C5
- 7323 D5
- 7331 B4
- 7332 B5
- 7333 B5
- 9300 F4

1 2 3 4 5 6 7


D1 ITT AUDIO DECODING

To 0240 of **A5**


To 0239 of **A5**




* 7803 MSP3415D




1 2 3 4 5 6 7



- 0239 D2
- 0240 B2
- 0248 E3
- 0248A E4
- 0257 D11
- 0258 D11
- 1801 B9
- 2801 C3
- 2802 C4
- 2803 C5
- 2804 D5
- 2805 B10
- 2806 B10
- 2807 E5
- 2808 F5
- 2809 E5
- 2810 E5
- 2811 D5
- 2812 D5
- 2814 B7
- 2815 D5
- 2816 F5
- 2817 F5
- 2818 E5
- 2819 E5
- 2820 C5
- 2821 C5
- 2822 B6
- 2823 B7
- 2824 B6
- 2825 B8
- 2826 F8
- 2827 E11
- 2828 E11
- 2829 F11
- 2830 F11
- 2831 B8
- 2832 B6
- 2833 B6
- 2834 B6
- 2835 B6
- 2836 B9
- 2837 B11
- 2838 B11
- 2839 B11
- 2840 B11
- 2841 G6
- 2842 H5
- 2843 D10
- 2844 D10
- 3801 C4
- 3802 C4
- 3803 C4
- 3804 C4
- 3805 C4
- 3806 C5
- 3807 E11
- 3808 F11
- 3809 B8
- 3810 A11
- 3811 B11
- 3812 G5
- 3813 E5
- 3814 E4
- 3815 F4
- 3816 F5
- 3899 D2
- 4801 C4
- 4802 D5
- 4803 E4
- 4804 E4
- 4805 F3
- 4806 E4
- 5801 C4
- 5802 C3
- 5811 G6
- 5812 H6
- 5813 H6
- 5814 H5
- 6801 B8
- 6802 G5
- 7801 C5
- 7802 B5
- 7803 F6
- 9801 E4
- 9802 E4
- 9803 F3
- 9804 E4
- 9810 D11
- 9811 D11



D2 ITT AUDIO AMPLIFIER



SOUND SYSTEM


.	EUROPE-NICAM/2CS		NAFTA/LATAM-BTSC		AP-NICAM/2CS/Multi-Mono		AP-RF-Mono/AV-Stereo	
	Side AV	No Side AV	Side AV	No Side AV	Side AV	No Side AV	Side AV	No Side AV
0248	Yes	-	Yes	-	Yes	-	Yes	-
2801	22p	22p	22p	22p	22p	22p	-	-
2804	22p	22p	22p	22p	22p	22p	-	-
2811	-	-	-	-	-	-	220n	220n
2812	-	-	-	-	-	-	1n	1n
2827	10u	10u	4u7	4u7	4u7	4u7	4u7	4u7
2837	100p	100p	47p	47p	47p	47p	47p	47p
2838	100p	100p	47p	47p	47p	47p	47p	47p
3899	5k6	4k7	-	-	-	-	-	-
4801	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper	-	-
4802	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper	-	-
4803	Jumper	-	-	-	-	-	-	-
4804	Jumper	-	-	-	-	-	-	-
4805	-	-	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper
4806	-	-	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper
5801	15u	15u	22u	22u	15u	15u	-	-
7803	MSP3415D	MSP3415D	MSP3435G	MSP3435G	MSP3415D	MSP3415D	BSP3505D	BSP3505D
9801	Jumper	Jumper	-	-	-	-	-	-
9802	Jumper	Jumper	-	-	-	-	-	-
9803	-	-	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper
9804	-	-	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper

MSP/BSP SOUND DIVERSITY TABLE

	SOUND AMPLIFIER	
	2x1W	2x3W
2954	-	100n
2957	220n	-
2965	-	220n
7953	TDA7053A	-
7954	-	TDA7057AQ
9958	Jumper	-


HEADPHONE

	Headphone	No Headphone
0247	Yes	-
9950	-	Jumper
9952	-	Jumper



- 0104 A4
- 0246 B10
- 0247 B11
- 2950 E3
- 2951 E5
- 2952 C4
- 2953 B4
- 2954 A7
- 2955 D10
- 2956 E5
- 2957 C7
- 2958 C9
- 2959 C9
- 2960 C9
- 2961 C9
- 2962 C4
- 2963 C4
- 2964 E6
- 2965 A7
- 2966 A7
- 3950 E3
- 3953 E5
- 3961 C3
- 3962 C3
- 3963 C3
- 4988 E9
- 4990 D10
- 6953 E4
- 7953 B6
- 7954 C6
- 7956 E4
- 9950 B9
- 9952 B9
- 9958 D10

- 0250-A C2 0250-C B2 0252 B2 0261 D5 1153 D3 2171 D4 2173 C3 3150 D4 3152 C4 3155 A4 6161 A3 9153 B3
 0250-B D2 0251 B5 0253 A5 1152 A3 1154 C3 2172 C4 2174 D3 3151 C3 3153 B3 5010 C4 9152 C3 9155 C4



8. Alignments

General: the Service Default Mode (SDM) and Service Alignment Mode (SAM) are described in chapter 5.

8.1 Alignment conditions

All electrical adjustments should be performed under the following conditions:

- Supply voltage : 220V - 240V (10%)
- Warm-up time: 10 minutes
- The voltages and oscillograms are measured in relation to the tuner earth.
- Test probe: $R_i > 10M\Omega$ $C_i < 2,5$ pF.

8.1.1 Selection of the SDM-menu

- By transmitting the "DEFAULT" command with the RC7150 Dealer Service Tool (this works both while the set is in normal operation mode or in the SAM)
- Standard RC sequence 062596 (within OSD time-out) MENU
- By shorting test-point 0228 and 0224 on the mono-carrier while switching on the set. After switching on the set the short-circuit can be removed. (Caution!! Override of 5V protections).

8.1.2 Selection of the SAM-menu

- By transmitting the "ALIGN" command with the RC7150 Dealer Service Tool
- By pressing the "CHANNEL DOWN" and "VOLUME DOWN" key on the local keyboard simultaneously when the set is in SDM
- Standard RC sequence 062596 (within OSD time-out) OSD
- By shorting test-point 0225 and 0226 on the mono-carrier while switching on the set. After switching on the set the short-circuit can be removed. (Caution!! Override of 5V protections).

8.2 Electrical Alignments

8.2.1 VG2

- Use a pattern generator to display a normal black picture.
- Program the pattern generator with a frequency of 475.25 MHz for PAL/SECAM and select L' for France
- Switch on the TV set.
- Select the SDM-MENU. The tuner is set to a frequency of 475.25 MHz.
- Select the " SAM-MENU".
- Press the "MENU" key on the RC to leave the SAM-MENU and go to the normal user menu ("SAM" remains displayed at the top of the screen). Select with the MENU UP/DOWN command the sub-menu BRIGHTNESS. Change the default value from 31 to 50 with the MENU LEFT/RIGHT keys. Select the CONTRAST sub-menu and change the value from 31 to 0.
- Leave the normal user menu to return to the SAM-MENU, by pressing the MENU key on the RC.
- Select sub-menu VSD and change the value from 0 to 1 by pressing the MENU LEFT key. CAUTION!! Depending on the position of the VG2 potentiometer, the screen will turn completely black because the Vertical Scan has been disabled.
- Adjust with VG2 potentiometer (positioned at LOT 5545) the blue line at the middle of the screen till this line is just not visible.

- The alignment of the VG2 has been completed; Switch the set to Standby. The values adapted at the BRIGHTNESS- and the CONTRAST-menu during the alignment, will change back again to their default values.

8.2.2 Focusing

Set pattern generator (e.g. PM5418) with Circle and Small Squares pattern and connect to aerial input with RF signal amplitude - 10mv. Adjusted with focusing potentiometer (positioned at LOT 5545) for maximum sharpness of the picture.

8.2.3 Adjustment of the Power Supply

- Set pattern generator (e.g. PM5418) with Circle and Small Squares pattern and connect to aerial input with RF signal amplitude - 10mv.
- Switch on the set.
- Select the 300Vdc voltage range when using a normal multi-meter.
- Connect the DC multi-meter to capacitor 2409.
- Adjust potentiometer R3540 till the DC multi-meter indicates 95V.

8.3 SOFTWARE ADJUSTMENT

8.3.1 Geometry adjustments

- Set pattern generator (e.g. PM5418) with Circle and Small Squares pattern on 475.25 MHz for PAL/SECAM and connect to aerial input with RF signal amplitude - 10mV, France select L'-signal.
- First enter the SDM mode to set the tuner at 475.25 MHz.
- Enter the SAM mode and then select GEOMETRY with the up/down keys buttons on the RC the respective items can be selected. Use the left/right buttons to adjust the selected items to correct the picture geometry as stated below.

Vertical Amplitude and Position

- Select Vertical Slope "VSL" and shift the test pattern to the top. The text VSL and its value should be above the upper half of the screen
- Select Service Blanking "SBL" and set it to 1. The lower half of the picture will be blanked.
- Press the up button once to select Vertical Slope "VSL". Now align "VSL" to start the blanking exactly at the horizontal white line at the centre of the test circle. "VSL" has the correct value now and should not be changed anymore.
- Press the down button once to select "SBL" and set it back to 0. The full picture reappears.
- Now select Vertical Amplitude "VAM" and align the picture height to the top of the screen, so that the top horizontal line just disappears. This corresponds with an over scan of approx. 6%.
- Select Vertical Shift "VSH" and align for vertical centring of the picture on the screen.
- Repeat the last two steps if necessary.

Select Vertical S-correction "VSC" to align the top/bottom squares till they have the same size as the squares in the middle of the screen.

Horizontal Amplitude and Phase

- Select Horizontal Shift "HSH" to horizontally centre the picture on the screen

To go back to the main SAM-menu , press the MENU key on the RC.

To leave the SAM-menu and store the alignments in the NVN, press the STANDBY-key on the RC.

8.3.2 AGC

Set pattern generator (e.g. PM5418) with colour bar pattern and connect to aerial input with RF signal amplitude - 10mV and set frequency for PAL/SECAM to 475.25 MHz. For France select the L'-signal.

- Select the " SAM-MENU.
- Select at the TUNER sub-menu the option AFW and select the lowest value.
- Select the AGC subsub-menu
- Connect a DC multi-meter at pin 1 of the tuner IC 1000.
- Adjusting the AGC until the voltage at pin 1 of the tuner is 1.0V +/- 0.1V.
- The value can be incremented or decremented by pressing the right/left MENU-button on the RC.
- Switch the set to standby.

8.3.3 IF-PLL / IF-PLL POS

Set pattern generator (e.g. PM5418) with colour bar pattern and connect to aerial input with RF signal amplitude - 10mV and set frequency for PAL/SECAM to 475.25 MHz.

- Select the " SAM-MENU".
- Select at the TUNER sub-menu the option AFW and select the lowest value.

Within the TUNER-menu we now have two options : IF-PLL and IF-PLL POS.

The IF-PLL option is used for all PAL/SECAM signal excluding SECAM L'.

The IF-PLL POS option is used for only the SECAM L' signal For the IF-PLL option the following should be done:

- Select at the TUNER menu the IF-PLL subsubmenu
- Adjust the IF-PLL value until the AFA becomes "1" and AFB alternates between "0" and "1"
- Switch the set to Standby or go to the IF-PLL POS menu.

For the IF-PLL POS option the following should be done:

- Change the signal at the pattern generator from PAL to SECAM and select the L'-signal.
- Select at the TUNER menu the IF-PLL POS subsubmenu.
- Adjust the IF-PLL POS value until the AFA becomes "1" and AFB alternates between "0" and "1"
- Switch the set to Standby or go to the IF-PLL menu.

8.3.4 Tuner options CL, YD and IF-PLL OFFSET

NO ADJUSTMENTS NEEDED FOR THESE ALIGNMENTS.

The tuner option code IF-PLL-OFFSET is only used in combination with sets with the TDA8845 BiMOS (IC7250).

(Typically this is for Secam LL'). The default values for these option codes are:

- CL : 4
- YD : 12
- IF-PLL-OFFSET : 48

8.3.5 White tone

- Connect a pattern generator (e.g. PM5418) and set it to colour bar and circle pattern.
- Set frequency for PAL 475.25MHz with RF signal amplitude - 10mv and connect to tuner (aerial) input
- Enter the SAM -MENU.
- Enter into WHITE TONE menu, select item NORMAL, DELTAWARM, or DELTACOOOL depending on the item which has to be aligned. Only one of the three items (R, G or B) will be displayed on the screen.

The default values for the colour temperature as displayed in the table below:

NORMAL	11500K	R = 40	G = 40	B = 40
(DELTA)COOL	13500K	R = -2	G = 0	B = 6
(DELTA)WARM	8500K	R = 2	G = 0	B = -7

Switch the set to standby.

Audio

NO ADJUSTMENTS NEEDED FOR SOUND.

The default values for the audio alignments as displayed in the table below:

AUDIO Alignment Options	
A-FM	232
AT	4
STEREO	15
DUAL	15

8.4 Options

Options are used to control the presence / absence of certain features and hardware. There are two ways to change the option settings. The various option configurations and the descriptions of the two character-codes are explained below. Changing a single option:

A single option can be selected with the MENU UP/DOWN keys and its setting can be changed with the MENU LEFT/ RIGHT keys.

Changing multiple options by changing option byte values: Option bytes make it possible to set very fast all options. An option byte represents a number of different options. All options of the L9 are controlled via 7 option bytes. Select the option byte (OB1, OB2, OB3, OB4, OB5, OB6 or OB7) and key in the new value.

Changes in the options and option bytes settings are saved when the set is switched to standby. Some changes will only take affect after the set has been switched OFF and ON with the mains switch (cold start).

The following options in SDM can be identified:

OP	OPTION (ON=enabled / present)	Explanation / Remark
AC	Alternate Channel	Alternate channel function (SWAP between last presets) enabled
AM	Animated menu	
2X	External 2	
AO	Audio out	Default value is OFF
AS	Auto startup/Micro controller startup	Default value is ON (ON = start-up via micro controller, OFF = auto start-up BiMOS)
AT	Automatic Tuning System (ATS)	
BM	Blue Mute (ON = enabled)	Enabled: blue mute background in case of no video ident /poor signal conditions

BS	BiMOS standby mode	Default value = ON
BT	Bass/Treble Control	Menu controls for BASS and TREBLE available when enabled
C8	Maximum Program (ON = 80 programmes)	C8 is OFF : Maximum of 100 programs
CD	Auto Cable Detect	Default value = OFF (Not applicable for European sets)
CI	Automatic Channel Installation (ACI)	
CK	Clock (Volatile)	Clock function available when enabled
CL	Child Lock	Menu item Child lock/Parental control when enabled
CP	Contrast Plus	Menu item Contrast Plus available when enabled
CT	Colour Temperature	Menu item Colour Temperature available when enabled
CX	16:9 Compress	Menu item 16:9 compress when enabled
DM	Demo Mode	Demonstration of TV functions on screen when enabled
DP	Slider Bar Value Display	Slider bar value displayed when enabled
DU	Dual I/II	Possibility of language selection when enabled
DV	Delta Volume	(Delta) Volume is stored separately for channel 0..40 and external sources when enabled; OFF = not available
EW	East-West Control	East-West Alignment in SAM GEOMETRY menu available when enabled
EX	4:3 Expand	4:3 expand mode available when enabled
FV	Favourite page	Favourite TXT-page feature present when enabled
FQ	Frequency display	Frequency displayed when enabled
GM	Games Mode	Optimisation of setting for games possible when enabled
HS	Hospital Mode	Possibility to block the local keyboard when enabled
HT	Hotel Mode	Possibility to pre-select the channel numbers when enabled
IS	Incredible Surround	Incredible surround function available when enabled
LV	Automatic Volume Leveller (AVL)	Menu item AVL available when enabled
NI	No Ident Auto Standby	Set switches to standby after 10min. when NI enabled
NR	Noise Reduction	Menu item Noise Reduction available when enabled
RC (*)	Separate preset/volume control on remote control (ON = separate control (A8 RC); OFF = combined control (L7 RC))	See note below table. Default value is OFF
SB	Sound Board (Set the sound hardware configuration)	MA = Mono ALL ND = Stereo/2CS/Nicam IT = German 2CS
SP	Smart Picture	Smart picture command is processed when enabled
SS	Smart Sound	Smart sound command is processed when enabled
ST	Sound systems supported	SS = BG, I, DK, M AD = BG/I, BG/DK, I/DK
SY	Systems supported	SS = Single system without NTSC Playback SP = Single system with NTSC Playback AD = Dual Mono ED = Europe Tri Mono EF = Europe Full Multi EL = Europe Full Multi with LL'
TN	Tuner (OFF: Philips tuner; ON: Alps tuner)	Default value = OFF
TW	Channel Select Time Window (OFF: 2 seconds; ON: 5 seconds)	Time interval for entering a second digit for channel selection
UB	Ultra Bass	Ultra bass function available when enabled
VI	Virgin Mode	OSD at very first installation when enabled
VL	Volume Limiter	Menu item Volume Limiter available when enabled
VM	Video Mute	Screen blanking during channel switching when enabled
WE	Europe West (ON: Western Europe; OFF: other)	
XS	External Source Colour Select	External source colour selection available when enabled
XT	External 1	External 1 source input available when enabled
OB1	Option Byte 1	See option bits
OB2	Option Byte 2	See option bits
OB3	Option Byte 3	See option bits
OB4	Option Byte 4	See option bits
OB5	Option Byte 5	See option bits
OB6	Option Byte 6	See option bits
OB7	Option Byte 7	See option bits

(*) Remark: When option RC = OFF, the P+ and the P- key on the remote control have the same functions as the MENU UP/DOWN keys while the VOL+ and the VOL- key have the same function as the MENU LEFT/RIGHT keys. When RC=OFF, it is not possible to change the channel preset or to adjust the volume in SAM/SDM with the remote control.

RC = OFF for use with L7-based remote control (only cursor keys). RC = ON for use with A8-based remote control (cursor keys, P+/P- and Volume+/Volume-).

8.5 Option bits/bytes

Option bytes

OB1 bits 8, 7, ..., 1: DP, FQ, AM, HS, HT, DM, GM, VI

OB2 bits 8, 7, ..., 1: CK, CL, AT, CI, (res), (res), SS, SP

OB3 bits 8, 7, ..., 1: RC, WE, (res), (res), TW, AC, C8, VM

OB4 bits 8, 7, ..., 1: TN, FV, XT, 2X, XS, CD, BM, NI

OB5 bits 8, 7, ..., 1: EX, CX, NR, CP, CT, EW, BS, AS

OB6 bits 8, 7, ..., 1: BT, IS, VL, DV, UB, LV, DU, AO

OB7 bits 8, 7, ..., 1: ST, ST, SB, SB, SB, SY, SY, SY

An option byte value is calculated in the following way:

value "option bit 1" x 1 =

value "option bit 2" x 2 =

value "option bit 3" x 4 =

value "option bit 4" x 8 =

value "option bit 5" x 16 =

value "option bit 6" x 32 =

value "option bit 7" x 64 =

value "option bit 8" x 128 =

Total : value "option byte" =

9. Circuit description new circuits

Power supply (diagram A1)

9.1 Introduction

9.1.1 General

The switch mode power supply (Fixed Frequency) is mains isolated. The control IC7520 (MC44603A) produces pulses for driving FET 7518. Power supply regulation is achieved by using duty cycle control at a fixed frequency of nominal 70 kHz in normal operation. In stand-by, slow-start and overload situations the SMPS runs at frequencies other than 70 kHz.

Basic characteristics of this SMPS :

- Mains Isolated flyback Converter type
- Input range : 150 - 276 Volts AC
- Secondary voltage adjustment via potentiometer R3540 at the primary side
- IC7520 is featured with Slow-Start circuitry
- Protection Circuits
- Degaussing circuit

9.1.2 Output voltages

- AudioSupply 10V/14V (+18V) for the Sound amplifier (D2)
- Vbatt/MainSupply (+95V) for the Line deflection stage (A2), Tuner video IF (A5)
- Vaux / MainAux (+9.5V) for the Line Deflection (A2) and the Control (A7)

9.1.3 The switching periods of TS7518

The power supply duty cycle is dependent on the T-on of FET 7518. The FET is driven by pin 3 of IC7520. This IC controls the secondary voltage (VBATT via potentiometer 3540. The primary voltage at pin1-2 of transformer 5545 is rectified by D6537 and smoothed by C2537. The switching period of TS7518 can be divided into three main phases: Duty cycle T-on, T-off and T-dead.

- During T-on, FET 7518 conducts.
- Energy is stored in the primary winding (4-7) of transformer T5545 by using a linear increasing primary current. The slope depends on the rectified mains-voltage present across C2508. The T-on period is varied to provide regulation of the drive waveform at pin 3 of IC7520. By controlling the duty cycle of the SMPS in this way the (VBATT is controlled.
- During T-off, FET 7518 is switched off and therefore does not conduct. The energy is now transferred to the secondary side of the transformer and then supplied to the load via the secondary diodes (D6550, D6560 and D6570). The current through the secondary side of the transformer decreases until it reaches zero.
- During T-dead FET 7518 does not conduct .The voltage at the drain of the FET decays and eventually reaches the input voltage of approximately 300V.

9.2 Primary side

9.2.1 Mains input and degaussing

- Mains voltage: this voltage is filtered by L5500 and L5501, rectified by the bridge diode 6502 .. 6505 and then smoothed by C2508 which provides a DC input voltage of 300V DC for an ac input voltage of 230V.

- Degaussing : R3504 is a PTC. When switching "on" the set, the PTC is cold and has a low-ohmic value. This allows a very high degaussing current at initial power on. The PTC will then heat up due to the high current involved and becomes high-ohmic which reduces the degaussing-current. During normal operation, the degaussing current is signal.very small, because of the high impedance of PTC R3504.

9.2.2 Start up and take over

- Start-up : The start-up circuitry consisting of 3510, 3530 and 3529 use the voltage coming from the 230V AC mains to start-up IC7520 via the supply pin 1. The output drive waveform (pin 3) is blocked by using the ICs internal logic until the voltage on pin 1 reaches 14.5 Volts however with less than 14.5 volts on Pin 1 the IC only consumes 0.3mA. Once pin 1 reaches the 14.5 Volts threshold, IC7520 will start up (FET 7518 will conduct) and pin 1 sinks a typical supply current of about 17 mA. This supply current cannot be delivered by the start-up circuitry, so a take-over circuit must be present. If take-over does not occur then the voltage on pin 1 will decrease below 9V and IC7520 will switch off. The supply begins a new Start-up cycle, see top of this paragraph. This cycle will repeat itself and can be noticed by an audible hick-up sounding noise.
- Take over : During start-up a voltage across winding 1-2 is gradually built up. At the moment the voltage across winding 1-2 reaches approx. (14.5 Volts, D6540 start conducting and takes over the supply voltage Vpin 1 of IC7520 (take over current is approx. 17mA).

Note: This power supply is a FFS (= Fixed Frequency Supply) and not a SOPS (= Self Oscillating Power Supply).

9.3 Control circuitry

9.3.1 IC7520 control mechanisms

IC7520 controls the T-on time of FET 7518 in three different ways:

- "Primary-voltage-sensing" controls the secondary output voltages via the feedback voltage pin 14
- "Primary current sensing" controls the maximum primary current via the current sense voltage pin 7
- "Demagnetization control" prevents the transformer T5545 from going into saturation via the so-called "DEMAG" function at pin 8

9.3.2 Secondary voltage sensing (pin 14 of IC7520)

When the output voltage +VBATT increases (due to a reduction in the load) the primary voltage at winding 1-2 will increase, therefore the voltage across capacitor 2537 increases. This will reduce the on-time of FET 7518 due to an increase of the voltage present on pin 14.

In the event of an increase of the load (decrease of output voltage +VBATT), the control circuit will work in the opposite way to the explanation above.

9.3.3 Primary sensing (pin 7 of IC7520)

The current sense voltage at pin 7 is used to measure the primary current through FET7518. The primary current is converted into a voltage by R3518.

9.3.4 Demagnetization control (pin 8 of IC7520)

Winding 1-2 has the same polarity as the secondary winding that supplies the load. When FET 7518 is turned off the voltage at winding 1 becomes positive. The power supply transfers the stored energy at the secondary side. Until the transformer is demagnetized the voltage on the winding remains positive. At the moment that the energy is fully transferred to the load, the voltage at pin 9 of the transformer becomes negative. Additionally with a certain dead time the voltage at control pin 8 of IC 7520 also drops below zero which releases the output buffer (pin 3) and a new cycle starts.

9.3.5 Peak current limiting

An internal clamp at pin 7 allows peak current limiting to be achieved. This pin can never exceed 1V DC and so the maximum primary current through FET 7518, and also the maximum output power is determined. In case of an output being short-circuited or loaded excessively, the I-prim becomes too high which is detected by pin 7. As a result the primary current is limited to its maximum value and the secondary voltages will drop. The voltage at pin 1, which is coupled with the output voltage, will also drop. When the voltage at pin 1 drops below the 9V, IC7520 will stop functioning and the output voltage will rapidly drop to zero.

Via start-up circuitry 3510, 3530 and 3529 the voltage originating from the 230V AC mains is used to start-up IC7520 via the supply pin 1. As soon as this voltage reaches the 14.5V, IC7520 starts functioning. If the load is still too much or the output is short-circuited the same cycle will happen again. This fault condition can be clearly identified as the power supply will be loudly tripping.

9.3.6 Slow-start

As soon as $V_{pin 1} > 14.5V$ the SMPS will start-up. During the slow-start procedure both the frequency and the duty cycle will be built up slowly. The duty cycle will initially slowly increase commencing with the absolute lowest possible duty cycle. The maximum duty cycle is determined by C2530 at pin 11 of IC7520, as C2530 is uncharged at start-up.

9.3.7 Standby mode

In standby mode the SMPS switches to the so-called "reduced frequency mode" and runs at about 20 kHz. During standby the SMPS only has to deliver a minimal level of output power. The minimal load threshold level is determined by R3532 at pin 12. In the L9 chassis the SMPS does not have a burst mode in standby but only a reduced frequency mode of about 20 kHz as stated above. In normal operation mode the internal oscillator is around 70 kHz. This frequency is controlled by C2531 at pin 10 of IC7520 and by R3537 at pin 16 of IC7520. In standby mode the frequency of operation is determined by R3536 at pin 15 of IC7520.

9.3.8 Protections

Over voltage protection of the secondary voltages.

After start-up the supply voltage pin 1 will be "taken over" by winding 1-2. Pin 1 of IC 7520 is used to detect an over voltage situation on the secondary side of the transformer. If this voltage exceeds 17V (typical), the output buffer is disabled, and IC 7520 goes into over voltage protection and a complete restart sequence is required. Check in this case IC7520, D6537 and the secondary voltage +VBATT (+95V).

REMARK: In the event of the over voltage situation remaining present, the SMPS will go in protection, start up cycle, protection, etc. The standby led on the front of the set starts flashing.

Under voltage protection of the secondary voltages

If the supply voltage at pin 1 of IC 7520 drops below 9V because of a short-circuit or excessive load, the drive pulse present at pin 3 will be disabled and IC7520 will switch off the complete SMPS. Capacitor C2540 is charged up via start-up resistors R3529, R3510 and R3530, however once the voltage exceeds 14.5V start up threshold, the SMPS will once again commence a re start cycle.

In the event of the under voltage situation remaining, the SMPS will again go in protection mode, start up cycle, protection, etc. and so the cycle repeats. This effect is highly audible.

9.4 Audio processing

The following systems are available:

- BASIC : FM MONO (M,BG, I and DK : single or dual system)
- NICAM : FM STEREO / NICAM L/L', NICAM I, NICAM B/G, NICAM DK
- 2CS : FM STEREO / FM MONO (all standards 4.5, 5.5, 6.5 MHz)

BASIC models incorporating 2CS (two carrier stereo) use a TDA8841/42 BIMOS device (built-in Mono FM Demodulator circuit)

NICAM LL', /BG, /I versions use a TDA8845 BIMOS (AM sound demodulator & QSS-IF circuit ; built-in)

The Audio Module incorporates the MSP3415 multi digital sound processor. This IC incorporates digital audio processing for volume, bass, Treble, balance, mute, spatial sound, incredible sound, smart sound and source selection (SIF-signal, EXT1 or EXT2).

9.4.1 Mono sets

The basic set, AM and FM, does not have the digital sound processor MSP3415 IC7833. Instead it is equipped with a SMART SOUND system. This circuit controls the bass and the treble via discrete components and two control signals (BASS and TREBLE) coming from the microprocessor.




Figure 9-10 "Mono AM Sets"

The video IF output is present at pin 11 of the tuner 1000. This signal goes through a sound SAW filter and is fed to the AM Mono Amplifier (Schematic A9 - IC7705) via pins 1 and 16, where the signal is demodulated. Mono Audio signals, ExtAudioMono, coming from the REAR I/O panel are fed to pin 9 of IC7705. The demodulated AM-signal or the REAR I/O signal is switched by IC7705. One of these signals is present at pin 6 for the I/O SCART, and present at pin 8 going to pin 2 of the BIMOS IC 7250-A. This signal is switched inside the BIMOS to pin15.

The signal at pin 15 is fed to panel A10 - SMART SOUND + MONO SOUND AMPLIFIER. After adjustments of the bass and treble, the signal goes to sound amplifier 7953 (2W - Mono).




Figure 9-11 "Mono FM sets "

The video IF output is present at pin 11 of the tuner 1000. This signal goes through a sound SAW filter and is fed to the BIMOS via pins 48 and 49, where the signal is demodulated. Depending on the required Tuner frequency band, the appropriate filter is selected. Signal LLp/Mtrap is used to switch between NICAM I or L'. At pin 6 of BIMOS IC 7250-A, the CVBS + SIF signal is fed to another SAW filter. The system hardware configuration, option code SY, is set at AD - Dual Mono for a Dual configuration, while option code SY is set at SS for the Mono configuration (BG,I, DK, M). Dual/ Mono, a signal coming from the Micro-processor IC7600, switches between two Mono configurations (BG/DK or BG/I or DK/I) and selects SAW filter 1001 or SAW filter 1002. This signal goes back to pin 1 of the BIMOS , for further demodulation. The demodulated FM-signal or the REAR I/O audio signal, EXTAudioMono, is switched by the Bimos and is present at pin 15 and pin 55. Pin 55 goes directly to the I/O SCART - AudioOutL/Mono. The signal at pin 15 is fed to panel A11 - SMART SOUND. After adjustments of the bass and treble, the signal goes to sound amplifier 7953 (2W - Mono). Signal Volume enables the output of the sound amplifier.

9.4.2 Nicam

This high quality digital audio format is used in Eastern Europe, Belgium, France, and UK, while NICAM LL' is being used in France. The figure below shows the AUDIO path for NICAM..




Figure 9-12 "NICAM"

Figure 9.2 "NICAM "

The video IF output is present at pin 11 of the tuner. Signal LLp/ Mtrap is used to switch between NICAM L or L'. Depending on the required Tuner frequency band, the appropriate SAW filter is selected. The filtered signal is fed to SIF (sound I.F amplifier) input pin 55 and 56 of the BIMOS - TDA8845. The QSS signal at pin 2 passes through a selected high pass filter, depending on the system used, and is fed to sound processor 7803, D1 - ITT panel. Audio signals coming from the REAR I/O panel are connected to pin 49/50 of IC7803 for the Ext1Audio signals, while pin 52/53 of IC 7803 are used for the Ext2 Audio signals.

The QSS-signal, Ext1Audio or Ext2Audio is switched internally to the output pins 28 and 29 of the sound processor. Pin 36 and 37 pass the same selected signal through to the SCART. The audio output of the MSP3415 is fed to the power amplifier IC 7953. Signal Volume enables the output of the sound amplifier.

9.4.3 2CS

This analogue F.M stereo audio standard is predominately used in Germany and The Netherlands. It is used on some cable television networks. The diagram below indicates the AUDIO path for 2CS. The CVBS + SIF signals present at pin 6 from BIMOS, - TDA884x-, are passed through a high pass filter and are then fed back into pin 58 of IC 7803 (MSP3415D) for further demodulation. All variants of 2CS are demodulated in this IC.




Figure 9-13 "2CS"

Audio signals coming from the REAR I/O panel are connected to pin 49/50 of IC7833 for the Ext1Audio signals, while pin 52/ 53 of IC 7803 are used for the Ext2Audio signals. IC 7803 performs source selection as well as audio processing such as volume, balance, tone control, mute, spatial stereo, incredible surround sound and SMART sound. The audio output from IC 7803, pin 28 and pin 29, is fed to the power amplifier IC 7953. Signal Volume enables the output of the sound amplifier.

9.5 Tuner and Video IF (see circuit diagram A5)

9.5.1 Introduction:

In Figure 9.15 a simplified block diagram of the video path is shown. The main item in the block diagram shown in Fig.9.14 is the video processor item 7250. The IC performs the following functions, video IF demodulation, chroma processing and RGB processing. Additionally synchronisation processing, mono IF audio demodulation and audio selection takes place.

- Two versions of video processors are used:
- TDA8841/42 N2 for SW CENELEC BG/DK, CENELEC I NICAM, CENELEC BG NICAM
 - TDA8845 N1 for CENELEC BG,LL',I
- For a detailed block diagram of the TDA8844/8845 see Figure 9.14.

Tuner

The PLL tuner (item 1000) is digitally controlled via the I2C-bus. The tuner is suitable to receive off-air, S-(cable) and hyper band channels.

Tuner pin description:

- Pin 1: AGC, Automatic gain control voltage input (0.3 - 4.0V)
- Pin 2: VT, tuning voltage input (not connected)
- Pin 3: AS, address select (not connected)
- Pin 4: SCL, IIC-bus serial clock
- Pin 5: SDA, IIC-bus serial data
- Pin 6: not connected
- Pin 7: Vs, PLL supply voltage +5V

- Pin 8: not connected
- Pin 9: Vst, tuning voltage +33V
- Pin 10: ground
- Pin 11: IF, asymmetrical IF output

Note: The +5V supply voltage and the +33V tuning voltage is derived from the line output stage, see diagram A2).

9.5.3 IF band pass filter (SAW FILTER)

Between the tuner output and the video IF input of the video processor the IF band pass filtering take place. For the IF band pass filtering SAW filters are used (item 1003 or 1005). 5 Types of SAW filters are used depending on the version of the set.

9.5.4 Video IF

General: Video IF-demodulation is achieved in combination with reference circuit L5006 connected at pin 3 and 4 of IC7250-A. The AGC control for the tuner is applied via pin 54 of IC7250-A. Internally the IC uses the top sync level as a reference for AGC control. The AGC adjustment can be readjusted via the SAM (service alignment menu). C2201 connected to pin 53 determines the time constant of the AGC. The Base band CVBS signal is present at pin 6 of IC7250-A (normal amplitude 3.2Vpp). From here the signal is fed via transistor 7266 to the sound trap filters and then on to the video source selection circuit.

The main functions of the video IF part are (see also figures 9.5):

- IF- amplifier
- PLL-demodulator
- Video buffer
- AFC
- IF-AGC
- Tuner AGC

9.5.5 IF- amplifier

The IF-amplifier incorporates symmetrical inputs (pins 48 and 49). By using IIC bus control (IFS) the AGC attenuation can be adjusted by up to -20dB.

Remark: If the BIMOS is replaced the AGC value should be adjusted as part of the repair process. (see Ch 8 - Alignments).

9.5.6 PLL-demodulator

The IF-signal is demodulated with the assistance of the PLL detector. The video IF-demodulator can handle both negative and positively modulated IF signals; selection is achieved via the IIC bus (bit MOD).

9.5.7 Video buffer

The video buffer is present to provide a low ohmic video output with the required signal amplitude. Additionally, it provides protection against (pin 6) the occurrence of noise peaks. The video buffer stage also contains a level shifter and a gain stage for both the positive and negative video modulation formats, so that the correct video amplitude and DC level are always present at pin 6 regardless of the input signal.

9.5.8 Video-IF AGC

An AGC system controls the gain of the IF amplifier such that the video output amplitude is constant. The demodulated video signal is supplied, via a low pass filter inside the IC to an AGC detector. External AGC de coupling is provided by capacitor 2201 at pin 53. The AGC detector voltage directly controls the IF amplification stages.

9.5.9 The tuner AGC

Tuner AGC is provided to reduce the tuner gain and thus the tuner output voltage when receiving to strong RF signal. The tuner AGC starts working when the video-IF input reaches a certain input level. This level can be adjusted via the IIC bus. The tuner AGC signal is applied to the tuner via the open collector output pin 54 of the BIMOS.

9.5.10 AFC

The AFC output information is available for search tuning. The AFC output is available via the I2C bus (AFA and AFB signals). For alignment purposes it is displayed in the TUNER submenu of the SAM (See chapter 8).




Figure 9-14 "BIMOS"

9.6 Video Signal Processing (see circuit diagram A6)

9.6.1 Introduction:

The video signal processing can be divided in the following parts:

- CVBS/Y/C input selection
- Luminance and chrominance signal processing
- PAL and SECAM demodulation /Auto system manager
- YUV/RGB processing/ black stretcher
- Second RGB insertion
- RGB processing
- Black current calibration loop
- Beaming current limiting

Above mentioned processing circuits are integrated in the TV-processor (parts B and C). The surrounding components are for the adaptation of the selected application. The I2C bus is used for defining and controlling the signals.




Figure 9-15 "Videopath"

9.6.2 CVBS/Y/C selection

The input switches are used for selection of the input signal. Three input signals can be selected:

- Pin 13: terrestrial CVBS input.
- Pin 17: external AV1 input.
- Pin 10/11: external AV2-Y, CVBS/C input

When pin 11 is in the CVBS input mode then pin 10 is not used. When pin 11 is in the Y/C input mode then both pins are used and the CHROMA filter in the Y signal path is switched off.

9.6.3 Luminance / Chroma signal processing

Once the signal source has been selected, CHROMA filter calibration is performed. The received colour burst-sub-carrier frequency is used for the calibration. Correspondingly, the CHROMA band-pass filter for PAL processing or the cloche filter for SECAM processing is switched on. Pins 34, 35 have the crystals connected to them. These crystals are used for multi-purpose calibration of the burst sub-carrier. The selected luminance signal is then supplied to the Horizontal and Vertical synchronisation processing circuits and to the luminance processing circuits. In the Luminance processing block, the luminance signal is applied to the CHROMA trap. This trap is switched on or off depending upon on the colour burst detection of the CHROMA calibration circuit. Before the luminance signal is applied to pin 28 of the TV-processor the signal is applied to a "peaking" and "coring" circuit. In these circuits the sharpness and noise level of the signal can be influenced via the remote control (control menu in the user menu).

9.6.4 PAL and SECAM demodulation via the Auto system manager

The colour decoder circuit detects whether the signal is a PAL signal. The result is made known to the auto system manager. The base-band delay line is activated when a PAL or SECAM signal is detected. For the SECAM colour standard a reference voltage is generated at pin 16 of the TV-processor. Connected at Pin 9 of the TV-processor, is the band-gap decoupling circuit, which consists of (2214,2215). The band-gap circuit provides a very stable and temperature independent reference voltage. It ensures optimal performance of the TV-processor and is used by almost all functional blocks inside the processor. The Y signal and the demodulator outputs R-Y and B-Y are present at pin 28, 29, 30 of the TV-processor. The auto system manager identifies PAL and SECAM colour standards and is controllable via the IIC bus. Connected on pin 36 of the TV-processor is the Loop Filter for the phase detector. The filter chosen provides an optimal transient response, which ensures both an optimum for noise bandwidth and colour acquisition time.

9.6.5 YUV / RGB processing/ black stretching

The signal Y, R-Y and B-Y present on pins 27, 31, 32 of the TV-processor are used as the input signals for the colour decoding section of the BIMOS (IC7520-C). The YUV processor enables the colour saturation control and also converts the Y, B-Y and B-Y signals to the R, G, B signal format via the colour matrix circuit. The black stretcher circuit, initial stage of the matrix circuit, extends the Grey signal level towards the actual black level. The amount of extension depends upon the difference between actual black level and the darkest part of the incoming video signal level. This feature is fully integrated. The user can switch this circuit on or off by using the Contrast Plus option in the user menu.

9.6.6 Second RGB insertion

Pins 23, 24, 25 are used as the inputs for the second R, G, B signals insertion. Pin 26 of the TV-processor is the input for the insertion control signal which is called "FBL". When the FBL signal level becomes higher than 0.9V (but less than 3V) the R, G, B signals at pins 23,24,25 are inserted into the picture by using the internal switches incorporated in the TV-processor. This second insertion possibility is used for insertion of the on screen display signals, TXT or R. G. B signals from the SCART socket.

9.6.7 RGB processing

The RGB processing circuit enables the picture parameters to be adjusted by using a combination of the user menus and the remote control. Additionally automatic gain control for the RGB signals via cut-off stabilisation is achieved in this functional block..

The block also inserts the cut off point "measuring pulses" into the RGB signals during vertical retrace period.. From outputs 19,20 and 21 the RGB signals are then applied to the output amplifiers on the CRT panel.

9.6.8 Black current calibration loop

The black current calibration loop ensures that the white balance at low signal levels and low light white balance is skipped. By means of the inserted measuring pulses, the black current calibration loop, tracks the beam current feed back of the RGB signals at the cathodes of the picture tube. As a result of this calibration, the individual black level of the RGB output signals is shifted to a level which allocates around 10uAof beam current to each of the RGB signals. Pin 18 (BC_info) of

the BIMOS is used as the feed back input from the CRT base panel.

9.6.9 Beam current limiting

A beam current limiting circuit inside the BIMOS handles the contrast and brightness control for the RGB signals. This prevents the CRT tube being over driven, which may cause serious damage in the line output stage. The reference used for this purpose is the DC voltage on Pin 22 (BLCIN) of the TV-processor. Contrast and brightness reduction of the RGB output signals is therefore proportional to the voltage present on this pin. Contrast reduction starts when the voltage on pin 22 is lower than 3.0 V. Brightness reduction starts when the voltage on pin 22 is less than 2.0 V.

The voltage on pin 22 is normally 3.3V (limitor not active). To enable correct operation however, an external adaptation to the circuit is required for the correct functioning of the limiting function. This is connected to Pin 22, the circuit therefore ensures that correct peak white limiting and the average beam current limiting takes place. Components 6212, 3246 are for the average beam current limiting. As a reference for the average beam current control the signal ABL_info is used. This signal is a measurement of the picture contents. As the time constant of the filter is much bigger than the frame period time, the DC at the anode of 6212 represents the average value of the picture content. Via 6212 and 2226 the DC voltage at pin 22 is slowly. The RGB output signals are applied to the CRT panel via connector 0243. Via diodes 6213, 6214 and 6215 and series resistor 3214, the RGB signals are also connected to the CRT_discharge signal. The level of this signal is only high during the time the set is switched off. And id due to the cathodes of the CRT are driven fully negative. That means that the beam current is increased. and consequently the CRT quickly discharged.

9.6.10 CRT panel (see circuit diagram B)

On the CRT panel the analog output amplifiers for the RGB signals are located.

The B-signal is amplified by the analog amplifier formed by a circuit build around the transistors 7331, 7332 and 7333.

The G- signal is amplified by the analog amplifier formed by a circuit build around the transistors 7321, 7322 and 7323. The R- signal is amplified by the analog amplifier formed by a circuit build around the transistors 7311, 7312 and 7313.

The supply voltage for the transistors is +160VA and is derived from the line output stage.

9.7 List of abbreviations

2CS	2 Carrier Stereo
A/P	Asia Pacific; schematic/PCB information (only) applicable for Asia Pacific sets
AFC	Automatic Frequency Control
AQUADAG	Aquadag coating on the (outside of the) picture tube
AudioOutR	Audio signal at Right output channel.
AudioOutL/Mono	Audio signal at Left output channel / Mono output channel.
AV_MUTE	Signal to mute the sound on the Audio-out of Cinch / Scart (Combined with RBG_Blanking)
Ext2Fun_SW (AV_Mute/ Ext2Fun_SW)	Switching signal from Scart2 to micro controller indicating the presence and type of signal on Scart2. (no signal / CVBS 16:9 / CVBS 4:3)
AV	Audio Video signal

AVL	Automatic Volume Level
B_TXT_OSD	Blue TXT or OSD signal from uC to the video controller IC7250 (BIMOS)
BASS	Control signal for BASS
BCI	Beam Current information
BTSC	Broadcast Television Standard Committee; sound standard for America and Asia Pacific
Buzzer	Buzzer (only used in L9-ITV)
CRT DISCHARGE	Fast drop of VBATT during after switch off the set. Which result in EHT voltage reducing to less than 18 kv within 5 sec.
CTI	Colour Transient Improvement
CVBS	Colour Video Blanking Synchronisation. Video signal containing colour, black/white, blanking and synchronisation information.
CVBS_EXT	CVBS external = CVBS signal form external source (VCR, DVD etc.)
CVBS_INT	CVBS internal = CVBS signal from the tuner
CVBS_MON	CVBS monitor (CVBS) signal to Cinch or Scart
CVBS_Terr	CVBS Terrestrial output signal
CVBS_TXT	CVBS for TXT processing in micro controller
Din	Digital input signal only used in L9-ITV)
Dout	Digital output signal (only used in L9-ITV)
DBX	Dynamic Bass Expander (only used for BTSC sound system)
DNR	Dynamic Noise Reduction
EAR	Earth (ground layer)
EEPROM	Electrically Erasable Programmable Read Only Memory (also called NVM; non-volatile memory)
EHT-INFO	Extra high tension information; Beam current related signal from CRT to BIMOS.
Ext1 B	RGB External 1 Blue input signal.
Ext1 FB	RGB External 1 Fast-blanking input signal.
Ext1 G	RGB External 1 Green input signal.
Ext1 R	RGB External 1 Red input signal.
Ext1 Video	RGB External 1 Video input signal.
Ext2 AudioL/Mono	External 2 Audio Left input signal / Mono input signal.
Ext Audio/Mono	External Audio input signal / Mono input signal.
Ext2 AudioR	External 2 Audio Right input signal.
Ext2C	External 2 SVHS Chrominance (C) input signal.
Ext2Video/Y	External 2 Video input signal or SVHS Luminance (Y) input signal.
ESD	Electrostatic Discharge
EURO	Europe; schematic/PCB information (only) applicable for European sets
EWD_dyn	Dynamic East-West correction to compensate for variations in EHT
EWDRIVE	East-West drive correction
FB_TXT_OSD	Fast blanking signal from micro controller to IC7250 (BIMOS) for inserting or displaying TXT and OSD information (generated by the micro processor)
Filament	Filament (heater voltage) from LOT to CRT
FBL	Fast Blanking
FFBL	Full screen Fast Blanking

FM/AM/ Ext_VC_AudioMono	FM, AM or external mono signal from BiMOS to audio processor input (only used in Mono and Nicam L sets)	P2LLp/Mtrap	Switching signal with several functions: M-trap (sound filtering) switching (only for A/P Pal Multi sets) BiMOS crystal selection (only for Latam sets), Selection of L or L' system (only for Europe sets)
Front/Ext1AudioL	Front audio Left input signal / External 1 Audio Left input signal.	P3Dual/Mono	Switching signal to select the sound filter in dual-system Mono sets (BG/I, BG/DK or I/DK).
Front/Ext1AudioR	Front audio Right input signal / External 1 Audio Right input signal.	P4ScartPin8/SVHS	Switching signal from I/O to micro controller with several functions: Scart1 I/O: detects signal type connected to Scart 1 (no signal, 16:9 signal, 4:3 signal) (only for Europe) Cinch I/O: detects signal type connected to cinch: SVHS or CVBS (not for Europe)
GND	Ground	P5BassSw	Bass switching signal (only for some mono sets)
GND_LOT	Ground of LOT	P6TrebleSw	Treble switching signal (only for some mono sets)
G_TXT_OSD	Green TXT or OSD signal from micro processor to the video controller IC7250 (BIMOS)	P7Ext1/2 P9stbyon+protn	Used in L9-ITV sets (Hotel TV) Signal from E-W and LOT output to micro controller to (de)activate the protection mode
HD	Horizontal pulse derivation	P10Mute/Volume POR/CLK	Audio mute / Volume control signal pin Power on reset (only used in L9-ITV sets)
HDRIVE	Horizontal output drive	R-	Power amplifier output " R- " to speaker
HEW_protn	Switching signal to (de)activate the XRAY protection which is measured via pin 50 of the BIMOS (only for USA sets)	R+	Power amplifier output " R+ " to headphone and speaker
Hflybk	Horizontal flyback pulse used to monitor the horizontal oscillator	RAM	Random Access Memory
IF	Intermediate Frequency signal from the tuner	RESET	Reset signal to micro controller
12C (or IIC)	2 Wire communication protocol between micro controller and integrated circuits	RF_AGC	Automatic gain control signal from BiMOS output to tuner input.
IC	Integrated Circuit	RGB	Red-Green-Blue
I/O	Input/Output	RGB_Blanking	Red Green Blue Blanking signal (combined with AV_MUTE)
INT	Audio internal output	RightOut	Audio right signal output
IR	Output signal from infrared receiver to micro controller.	R_TXT_OSD	Red TXT or OSD signal from uC to the video controller IC7250 (BIMOS)
KeyBd1	Local keyboard control signal to micro controller	ROM	Read Only Memory
KeyBd2	Local keyboard control signal to micro controller (In protection mode KeyBd2 is Ground)	SAM	Service Alignment Mode. Service mode for alignments and error buffer display
KeyBd3	Local keyboard control signal to micro controller	SAP	Second audio program (only for USA & A/P sets)
L-	Power amplifier output to headphone and speaker	SCL	Clock line of the I2C-bus
L+	Power amplifier output to speaker	SCL2	2nd Clock line of the IIC-bus (only used in L9-ITV sets)
LED	LED control signal from micro controller to LED	SDA	Data line of the I2C-bus
LATAM	Latin America; schematic/PCB information (only) applicable for Latin American (incl. Brazilian) sets	SDA2	2nd Data line of the I2C-bus (only used in L9-ITV sets)
LeftOut	Audio Left signal output	SDM	Service Default Mode. Service mode with predefined settings for waveform and voltage measurements, error buffer display and option (byte) setting.
LTI	Luminance Transient Improvement (= steepness)	SIF	Sound IF signal for FM audio demodulator
MainAudioL/Mono	Audio Left/Mono signal to input power amplifier	SMPS	Switching Mode Power Supply
MainAudioR	Audio Right signal to input power amplifier	STANDBY	Switching signal from micro controller; "low" for standby (power supply will be switched to stand-by mode), "high" for normal operation
MON	Audio monitor output	SW_OUT	Selected Output signal from source
NICAM	Near Instantaneous Companded Audio Muxplex (digital audio)	SYNC	Synchronisation
NR	Noise Reduction	TBD	To Be Defined
NTSC	NTSC colour system	TREBLE	Control signal for treble
OSD	On Screen Display	TXT	Teletext
P0Sys1/AM	Switching signal with several functions:	µC	Micro controller
BiMOS crystal selection (only for Latam sets)	Selection of AM or FM signal (used in combination with P1Sys2/AMFM_ExtSel) (only for Europe)		
P1Sys2/ AMFM_ExtSel	Switching signal with several functions: BiMOS crystal selection (only for Latam sets) Selection of internal AM/FM signal or an external signal (used in combination with P0Sys1/AM)		

USA	United States; schematic/PCB information (only) applicable for North American sets
V_TUNE	Tuning voltage for tuner
Vdrive -	Negative Vertical drive pulse signal
Vdrive +	Positive Vertical drive pulse signal
VD	Vertical pulse derivation
VFL	Vertical flyback pulse used to inform the micro controller that flyback is occurring. This is critical for the correct OSD and TXT
Vflybk	Vertical flyback pulse
VG2	Voltage on grid 2 of the picture tube (screen control)
VideoOut	CVBS output signal
VOLUME	Control signal (from micro controller, but on DC level via RC network) for sound processing in sound IC
XRAY-PROT	XRAY protection (only for USA sets)
YC	Luminance (Y) and Chrominance (C)

10. Spareparts list

MONO CARRIER [A]

Various

0025	4822 256 10336	LED HOLDER
0127▲	4822 256 92053	FUSE HOLDER
0130	4822 325 10164	INSULATING PLATE
0139	4822 492 70788	IC fixation
0189▲	4822 402 10844	PCB RELIEF BRACKET
0211▲	4822 265 20723	Conn. 2p
0218	4822 265 10481	CINCH CONNECTOR 2P
0224	4822 267 10676	Conn. 1p
0228	4822 267 10676	Conn. 1p
0229	4822 267 10735	Conn. 3p
0230	4822 267 10735	Conn. 3p
0231▲	4822 276 14024	Mains switch
0232▲	4822 267 31014	HEADPHONE SOCKET
0234	4822 267 10928	Conn. 5P
0249	4822 267 10565	Conn. 4P
0260	4822 267 10565	Conn. 4P
0267	4822 267 31673	HEADPHONE PLUG
1001	4822 242 10314	filt. 5,5MHz
1001	4822 242 10362	filt. 6,0MHz
1002▲	4822 242 10316	filt. 6,5MHz
1002	4822 242 10362	filt. 6,0MHz
1003	4822 242 10575	SAW filter OFWJ1980M (38,9MHz)
1003	4822 242 81436	SAW filter OFWK3953M (38,9MHz)
1003	4822 242 81737	SAW filter OFWG1965M (38,9MHz)
1003	4822 242 81964	SAW filt. OFWG1984M (38,9MHz)
1005	4822 242 11055	SAW filt. OFWK6289K (38,9MHz)
1200	4822 242 10315	cer. filt. 5,5/5,7/6,5MHz
1200	4822 242 81572	filt. 6,0MHz
1200	4822 242 81712	filt. 5,5/5,74MHz
1201	4822 242 81301	filt. 6,5MHz
1201	4822 242 81572	filt. 6,0MHz
1204	4822 242 10688	SAW filt. OFWK9456M (38,9MHz)
1205	4822 242 10695	X-tal 4.433619 MHz
1208	4822 242 10776	X-tal 3.579545 MHz
1500	4822 070 34002	Fuse (4A)
1571▲	4822 071 51002	Fuse (1A)
1572▲	4822 252 11194	Fuse (0,8A)
1600	4822 242 10694	X-tal 12MHz
1680	4822 276 13775	SWITCH
1681	4822 276 13775	SWITCH
1682	4822 276 13775	SWITCH
1683	4822 276 13775	SWITCH
1701	4822 242 81423	filt. OFWL9453M (38,9MHz)

-II-

2001	4822 126 13751	47nF 10% 63V
2002	4822 124 81029	100µF 20% 25V
2003	4822 124 81029	100µF 20% 25V
2004	5322 122 32654	22nF 10% 63V
2005	5322 122 32531	100pF 5% 50V
2006	4822 126 13695	82pF 1% 63V
2008	4822 124 41579	10µF 20% 50V
2012▲	4822 051 20008	JUMPER (0805)
2012	4822 122 33177	10nF 20% 50V
2014	5322 122 32967	5.6pF 10% 63V
2101	5322 122 31863	330pF 5% 63V
2102	5322 122 31863	330pF 5% 63V
2102	5322 122 32531	100pF 5% 50V
2103	5322 122 31863	330pF 5% 63V
2104	5322 122 31863	330pF 5% 63V
2104	5322 122 32531	100pF 5% 50V
2105	4822 124 81029	100µF 20% 25V
2106	4822 124 40769	4.7µF 20% 100V
2106	4822 124 41579	10µF 20% 50V
2107	5322 122 31863	330pF 5% 63V
2109	5322 122 31863	330pF 5% 63V
2171	5322 122 31863	330pF 5% 63V
2172	5322 122 31863	330pF 5% 63V
2173	4822 122 33805	330pF 10% 63V
2174	4822 124 41579	10µF 20% 50V
2176	4822 122 33805	330pF 10% 63V
2177	4822 124 41579	10µF 20% 50V
2201	4822 124 40242	1µF 20% 63V
2201	4822 124 41576	2.2µF 20% 50V

2202	5322 126 10465	3.9nF 10% 50V
2203	4822 124 41579	10µF 20% 50V
2205	4822 126 10002	100nF 20% 25V
2206	4822 122 33175	2.2nF 20% 50V
2207	4822 124 81029	100µF 20% 25V
2208	4822 126 13061	220nF 20% 25V
2209▲	4822 051 20008	JUMPER (0805)
2210	4822 126 10002	100nF 20% 25V
2211	4822 126 13196	100nF 10% 25V
2211	4822 126 13482	470nF 20% 16V
2212	5322 126 10511	1nF 5% 50V
2213	4822 126 10002	100nF 20% 25V
2214	5322 122 32654	22nF 10% 63V
2215	4822 124 41576	2.2µF 20% 50V
2216	4822 126 13061	220nF 20% 25V
2217	4822 126 13689	18pF 1% 63V
2218	5322 122 31866	6.8nF 10% 63V
2220	4822 126 10002	100nF 20% 25V
2221	5322 126 10511	1nF 5% 50V
2222	4822 126 10002	100nF 20% 25V
2223	4822 126 13751	47nF 10% 63V
2224	4822 126 13751	47nF 10% 63V
2225	4822 126 13751	47nF 10% 63V
2226	4822 124 41579	10µF 20% 50V
2227▲	4822 051 20008	JUMPER (0805)
2227	4822 126 13482	470nF 20% 16V
2228	4822 126 13692	47pF 1% 63V
2229	4822 126 13692	47pF 1% 63V
2230	4822 126 13692	47pF 1% 63V
2231	4822 122 33177	10nF 20% 50V
2232	4822 122 33175	2.2nF 20% 50V
2233	4822 124 40242	1µF 20% 63V
2234	5322 126 10223	4.7nF 10% 63V
2235	5322 126 10511	1nF 5% 50V
2236	4822 126 13061	220nF 20% 25V
2237	5322 122 32531	100pF 5% 50V
2238	4822 126 13486	15pF 2% 63V
2239	5322 121 42386	100nF 5% 63V
2240	5322 126 10511	1nF 5% 50V
2241	5322 126 10511	1nF 5% 50V
2242	4822 124 40242	1µF 20% 63V
2243	4822 126 13061	220nF 20% 25V
2244	4822 124 41579	10µF 20% 50V
2245	4822 124 40769	4.7µF 20% 100V
2248	4822 126 13486	15pF 2% 63V
2250	4822 122 33805	330pF 10% 63V
2255	5322 122 32531	100pF 5% 50V
2400	4822 121 43526	47nF 5% 250V
2401	4822 121 43526	47nF 5% 250V
2402	5322 122 31863	330pF 5% 63V
2403	4822 126 11501	1.5nF 10% 500V
2405▲	4822 126 14237	470pF 10% R 2KV
2406▲	4822 126 13866	4.7nF 10% 1KV
2407▲	4822 121 70434	11nF 5% 1.6KV
2407▲	4822 121 70637	8.2nF 5% 1600V
2407▲	4822 121 70649	9.1nF 5% 1.6KV
2408	4822 122 30103	22nF 80% 63V
2409	4822 124 11575	47µF 20% 160V
2410	4822 124 11767	470µF 20% 25V
2411	4822 124 40242	1µF 20% 63V
2412	4822 121 51385	33nF 20% 100V
2413	4822 124 11845	22µF 20% 250V
2414	4822 124 81145	1000µF 20% 16V
2415	4822 124 81145	1000µF 20% 16V
2416	4822 126 12239	560pF 10% 2KV
2417	4822 124 11767	470µF 20% 25V
2418	4822 126 13482	470nF 20% 16V
2420	4822 126 14096	560nF 5% 250V
2431	4822 124 12438	2.2µF 20% 100V
2432	4822 124 80059	100µF 20% 25V
2460	5322 122 32268	470pF 10% 50V
2461	5322 126 10184	820pF 5% 50V
2462	5322 122 32268	470pF 10% 50V
2463	5322 121 42386	100nF 5% 63V
2464	4822 124 40255	100µF 20% 63V
2465	5322 121 42386	100nF 5% 63V
2466	4822 121 42408	220nF 5% 63V
2467	5322 121 42386	100nF 5% 63V
2470	5322 126 10223	4.7nF 10% 63V
2500▲	4822 126 13589	470nF 275V
2502▲	4822 126 14153	2.2nF 10% 1KV
2504▲	4822 126 14153	2.2nF 10% 1KV
2505▲	4822 126 14153	2.2nF 10% 1KV
2508	4822 124 12439	100µF 20% 400V
2509▲	4822 126 11382	1nF 10% 1KV
2509▲	4822 126 13517	820pF 10% 1000V

2510▲	4822 126 11382	1nF 10% 1KV
2510▲	4822 126 13517	820pF 10% 1000V
2517	5322 122 32331	1nF 10% 100V
2518▲	4822 126 13337	220pF 10% 1KV
2520	4822 126 13695	82pF 1% 63V
2521	4822 122 32646	5.6nF 10% 50V
2521	5322 126 10223	4.7nF 10% 63V
2522	4822 122 32646	5.6nF 10% 50V
2522	5322 126 10223	4.7nF 10% 63V
2524	5322 122 32268	470pF 10% 50V
2529	4822 126 14118	100nF 20% 50V
2530	4822 124 11571	1µF 20% 50V
2531	4822 126 14587	560pF 2% 50V
2533	5322 122 31863	330pF 5% 63V
2534	5322 126 10511	1nF 5% 50V
2537	5322 121 42386	100nF 5% 63V
2540	4822 124 80059	100µF 20% 25V
2541	4822 121 10686	4.7nF 10% 50V
2545▲	4822 126 14049	1.5nF 20% 250V
2550▲	4822 126 11382	1nF 10% 1KV
2551	4822 124 42336	47µF 20% 160V
2560	5322 122 34123	1nF 10% 50V
2561	4822 124 81145	1000µF 20% 16V
2570	4822 122 33175	2.2nF 20% 50V
2571	4822 124 12417	2200µF 20% 25V
2572	5322 122 32531	100pF 5% 50V
2600	4822 124 81151	22µF 50V
2601	4822 124 81151	22µF 50V
2604	4822 126 10002	100nF 20% 25V
2605	4822 126 10002	100nF 20% 25V
2606	4822 126 10002	100nF 20% 25V
2607	5322 126 10511	1nF 5% 50V
2608	4822 121 43897	1nF 5% 400V
2609	4822 126 10002	100nF 20% 25V
2610	4822 121 42687	3.3nF 10% 63V
2611	4822 126 10002	100nF 20% 25V
2612	5322 122 32654	22nF 10% 63V
2613	4822 126 13695	82pF 1% 63V
2614	4822 126 13695	82pF 1% 63V
2615	5322 122 32531	100pF 5% 50V
2616	5322 122 32658	22pF 5% 50V
2617	5322 122 32658	22pF 5% 50V
2618	4822 122 33177	10nF 20% 50V
2619	4822 126 13061	220nF 20% 25V
2620	5322 122 32531	100pF 5% 50V
2621	5322 122 32531	100pF 5% 50V
2622	5322 122 32531	100pF 5% 50V
2623	5322 122 32531	100pF 5% 50V
2624	4822 126 10002	100nF 20% 25V
2625	4822 122 33575	220pF 5% 63V
2625	5322 122 32531	100pF 5% 50V
2651	4822 124 81029	100µF 20% 25V
2675	4822 126 13482	470nF 20% 16V
2680	4822 124 41579	10µF 20% 50V
2697	5322 126 10511	1nF 5% 50V
2702	4822 124 40769	4.7µF 20% 100V
2703	4822 124 40769	4.7µF 20% 100V
2704	4822 126 13061	220nF 20% 25V
2705	4822 126 13061	220nF 20% 25V
2706	4822 126 13061	220nF 20% 25V
2707	4822 126 13061	220nF 20% 25V
2709	4822 126 10002	100nF 20% 25V
2710	4822 124 41751	47µF 20% 50V
2950	4822 124 81151	22µF 50V
2951	4822 124 41579	10µF 20% 50V
2952	4822 122 33175	2.2nF 20% 50V
2953	4822 126 13061	220nF 20% 25V
2954	4822 126 13061	220nF 20% 25V
2955	4822 124 11767	470µF 20% 25V
2971	4822 121 51252	470nF 5% 63V
2972	4822 126 12105	33nF 5% 50V
2973	5322 121 42386	100nF 5% 63V
2974	4822 121 51379	82nF 5% 63V
2975	4822 122 33177	10nF 20% 50V

□

3000▲	4822 051 20101	100Ω 5% 0.1W
3001▲	4822 051 20101	100Ω 5% 0.1W
3002	4822 116 52244	15k 5% 0.5W
3003	4822 116 52238	12k 5% 0.5W
3013▲	4822 051 20008	jumper (0805)
3013	4822 117 10833	10k 1% 0.1W
3014	4822 051 20392	3k9 5% 0.1W
3015▲	4822 051 20153	15k 5% 0.1W
3016	4822 116 52228</	

3017▲	4822 051 20472	4k7 5% 0.1W	3272	4822 051 20273	27k 5% 0.1W	3611	4822 051 20822	8k2 5% 0.1W
3018	4822 117 11449	2k2 1% 0.1W	3273	4822 117 10833	10k 1% 0.1W	3612	4822 117 11503	220Ω 1% 0.1W
3020	4822 051 20223	22k 5% 0.1W	3274	4822 051 10102	1k 2% 0.25W	3613▲	4822 051 20332	3k3 5% 0.1W
3027	4822 117 11507	6k8 1% 0.1W	3275	4822 117 13579	220k 1% 0.1W	3614▲	4822 051 20332	3k3 5% 0.1W
3028	4822 117 11449	2k2 1% 0.1W	3276	4822 051 10102	1k 2% 0.25W	3615	4822 117 11454	820Ω 1% 0.1W
3029	4822 117 11449	2k2 1% 0.1W	3277	4822 051 20479	47Ω 5% 0.1W	3616	4822 117 12167	8k2 X12
3030	4822 117 11449	2k2 1% 0.1W	3278	4822 051 20479	47Ω 5% 0.1W	3617	4822 116 90885	8k2 X6
3031▲	4822 051 20472	4k7 5% 0.1W	3400	4822 053 12472	4k7 5% 3W	3618	4822 051 20561	560Ω 5% 0.1W
3032	4822 051 20223	22k 5% 0.1W	3402	4822 050 12709	27Ω 1% 0.4W	3619	4822 051 20391	390Ω 5% 0.1W
3100	4822 117 10353	150Ω 1% 0.1W	3403	4822 116 52289	5k6 5% 0.5W	3619▲	4822 051 20471	470Ω 5% 0.1W
3101	4822 117 13579	220k 1% 0.1W	3404▲	4822 117 13671	12k 5% 0.33W	3620	4822 050 12403	24k 1% 0.4W
3102	4822 050 11002	1k 1% 0.4W	3405▲	4822 052 10472	4k7 5% 0.33W	3622▲	4822 051 20101	100Ω 5% 0.1W
3103	4822 117 10834	47k 1% 0.1W	3406▲	4822 052 10472	4k7 5% 0.33W	3623▲	4822 051 20101	100Ω 5% 0.1W
3104	4822 117 10353	150Ω 1% 0.1W	3407	4822 117 12172	220Ω 5% 3W	3624	4822 117 13649	2k2 5% 7X
3105	4822 117 13579	220k 1% 0.1W	3411▲	4822 052 10108	1Ω 5% 0.33W	3625▲	4822 051 20101	100Ω 5% 0.1W
3106	4822 050 11002	1k 1% 0.4W	3412▲	4822 052 10108	1Ω 5% 0.33W	3626▲	4822 051 20101	100Ω 5% 0.1W
3107	4822 117 10834	47k 1% 0.1W	3414	4822 051 20182	1k8 5% 0.1W	3627	4822 117 10833	10k 1% 0.1W
3108	4822 116 52175	100Ω 5% 0.5W	3415	4822 116 52238	12k 5% 0.5W	3628	4822 116 52175	100Ω 5% 0.5W
3109	4822 051 20759	75Ω 5% 0.1W	3415	4822 116 83864	10k 5% 0.5W	3629▲	4822 051 20472	4k7 5% 0.1W
3110	4822 051 20759	75Ω 5% 0.1W	3416▲	4822 052 11398	3Ω 9% 0.5W	3630	4822 116 83884	47k 5% 0.5W
3111	4822 116 52175	100Ω 5% 0.5W	3417	4822 052 11108	1Ω 5% 0.5W	3631	4822 117 13579	220k 1% 0.1W
3112	4822 051 20759	75Ω 5% 0.1W	3420	4822 051 20759	75Ω 5% 0.1W	3632▲	4822 051 20472	4k7 5% 0.1W
3113	4822 116 52175	100Ω 5% 0.5W	3421▲	4822 051 20101	100Ω 5% 0.1W	3633	4822 116 52264	1k 2% 0.25W
3114	4822 116 52201	75Ω 5% 0.5W	3423	4822 116 83864	10k 5% 0.5W	3634	4822 051 20562	5k6 5% 0.1W
3115	4822 116 52175	100Ω 5% 0.5W	3424	4822 117 11507	6k8 1% 0.1W	3636	4822 117 11449	2k2 1% 0.1W
3116	4822 116 52201	75Ω 5% 0.5W	3425▲	4822 051 20101	100Ω 5% 0.1W	3639	4822 117 10353	150Ω 1% 0.1W
3118	4822 050 11002	1k 1% 0.4W	3431	4822 117 13579	220k 1% 0.1W	3640	4822 117 10353	150Ω 1% 0.1W
3119	4822 117 10834	47k 1% 0.1W	3432	4822 117 11149	82k 1% 0.1W	3641	4822 117 10353	150Ω 1% 0.1W
3120	4822 050 11002	1k 1% 0.4W	3433	4822 117 13579	220k 1% 0.1W	3642	4822 117 10353	150Ω 1% 0.1W
3121	4822 117 10834	47k 1% 0.1W	3434	4822 117 10834	47k 1% 0.1W	3643	4822 117 10833	10k 1% 0.1W
3122	4822 116 52244	15k 5% 0.5W	3435	4822 117 10833	10k 1% 0.1W	3644	4822 117 10833	10k 1% 0.1W
3123▲	4822 051 20472	4k7 5% 0.1W	3436	4822 116 52256	2k2 5% 0.5W	3650	4822 051 10102	1k 2% 0.25W
3124	4822 116 52201	75Ω 5% 0.5W	3440	4822 116 83864	10k 5% 0.5W	3651	4822 051 10102	1k 2% 0.25W
3125	4822 116 52175	100Ω 5% 0.5W	3441	4822 051 20223	22k 5% 0.1W	3652▲	4822 051 20471	470Ω 5% 0.1W
3128	4822 116 52201	75Ω 5% 0.5W	3460	4822 050 22202	2k2 1% 0.6W	3653▲	4822 051 20471	470Ω 5% 0.1W
3130▲	4822 051 20339	33Ω 5% 0.1W	3461	4822 051 10102	1k 2% 0.25W	3654	4822 051 20105	1M 5% 0.1W
3131▲	4822 051 20339	33Ω 5% 0.1W	3462	4822 051 10102	1k 2% 0.25W	3655	4822 116 52234	100k 5% 0.5W
3132▲	4822 051 20339	33Ω 5% 0.1W	3463▲	4822 052 10158	1Ω 5% 0.33W	3670	4822 051 20392	3k9 5% 0.1W
3133▲	4822 051 20472	4k7 5% 0.1W	3464	4822 050 22202	2k2 1% 0.6W	3670	4822 117 11449	2k2 1% 0.1W
3135▲	4822 051 20472	4k7 5% 0.1W	3465	4822 050 23308	3Ω 3% 1% 0.6W	3680	4822 051 20681	680Ω 5% 0.1W
3136	4822 116 52244	15k 5% 0.5W	3465	4822 050 24708	4Ω 7% 1% 0.6W	3681	4822 117 11449	2k2 1% 0.1W
3140▲	4822 051 20008	jumper (0805)	3465	4822 050 25608	5Ω 6% 1% 0.6W	3682	4822 116 52303	8k2 5% 0.5W
3141	4822 051 10102	1k 2% 0.25W	3466	4822 050 24708	4Ω 7% 1% 0.6W	3683▲	4822 051 20101	100Ω 5% 0.1W
3142▲	4822 051 20008	jumper (0805)	3466	4822 050 25608	5Ω 6% 1% 0.6W	3684▲	4822 051 20332	3k3 5% 0.1W
3143	4822 051 10102	1k 2% 0.25W	3467	4822 116 83872	220Ω 5% 0.5W	3707	4822 117 10834	47k 1% 0.1W
3150	4822 117 10834	47k 1% 0.1W	3468	4822 116 83872	220Ω 5% 0.5W	3709	4822 051 20273	27k 5% 0.1W
3151	4822 050 11002	1k 1% 0.4W	3470	4822 116 52251	18k 5% 0.5W	3710▲	4822 051 20472	4k7 5% 0.1W
3152	4822 117 10834	47k 1% 0.1W	3471	4822 051 20391	390Ω 5% 0.1W	3712	4822 116 83884	47k 5% 0.5W
3153	4822 050 11002	1k 1% 0.4W	3472	4822 116 52256	2k2 5% 0.5W	3713	4822 116 52245	150k 5% 0.5W
3156	4822 116 83876	270Ω 5% 0.5W	3473	4822 116 52175	100Ω 5% 0.5W	3950	4822 051 20273	27k 5% 0.1W
3157	4822 116 83876	270Ω 5% 0.5W	3474	4822 053 12229	22Ω 5% 3W	3953▲	4822 051 20332	3k3 5% 0.1W
3200	4822 051 20661	680Ω 5% 0.1W	3501	4822 117 12181	470Ω 20% 0.5W	3971	4822 117 11504	270Ω 1% 0.1W
3201	4822 116 83881	390Ω 5% 0.5W	3502▲	4822 053 21225	2M 5% 0.5W	3972	4822 051 10102	1k 2% 0.25W
3202	4822 051 20155	1M 5% 0.1W	3504▲	4822 117 12728	9Ω 200V	3973▲	4822 051 20471	470Ω 5% 0.1W
3204	4822 117 10353	150Ω 1% 0.1W	3506	4822 116 82776	2Ω 2	3974▲	4822 051 20008	jumper (0805)
3205	4822 051 10102	1k 2% 0.25W	3509	4822 117 12654	100Ω 5% 5W	3974	4822 117 11507	6k8 1% 0.1W
3206	4822 117 10353	150Ω 1% 0.1W	3510	4822 117 11488	33k 5% 3W	3975	4822 051 20562	5k6 5% 0.1W
3206	4822 117 11504	270Ω 1% 0.1W	3512	4822 117 10965	18k 1% 0.1W	3976	4822 051 20182	1k8 5% 0.1W
3207	4822 052 10338	3Ω 3% 5% 0.33W	3513	4822 117 13579	220k 1% 0.1W	3977	4822 051 20182	1k8 5% 0.1W
3208	4822 051 20829	82Ω 5% 0.1W	3517	4822 116 83864	10k 5% 0.5W	3978	4822 117 11383	12k 1% 0.1W
3208	4822 117 12521	68Ω 1% 0.1W	3518	4822 117 10422	0.33Ω 5% 3W	3979	4822 117 11503	220Ω 1% 0.1W
3212	4822 116 83883	470Ω 5% 0.5W	3520	4822 117 11149	82k 1% 0.1W	4xxx	4822 051 10008	0Ω 5% 0.25W
3213▲	4822 051 20471	470Ω 5% 0.1W	3521	4822 116 52219	330Ω 5% 0.5W	4xxx	4822 051 20008	0Ω 5% 0.25W
3213	4822 051 20561	560Ω 5% 0.1W	3524▲	4822 051 20008	jumper (0805)			
3214	4822 117 10353	150Ω 1% 0.1W	3525▲	4822 052 10229	22Ω 5% 0.33W	5004	4822 157 11892	0U22 10%
3216▲	4822 051 20008	jumper (0805)	3528	4822 116 83872	220Ω 5% 0.5W	5004	4822 157 71694	0U82 10%
3217	4822 117 11507	6k8 1% 0.1W	3528	4822 116 83876	270Ω 5% 0.5W	5006	4822 157 11534	78mH
3218▲	4822 051 20101	100Ω 5% 0.1W	3529	4822 050 24708	4Ω 7% 1% 0.6W	5100	4822 157 11813	3.3μH 5%
3219	4822 051 10102	1k 2% 0.25W	3530	4822 116 52276	3k9 5% 0.5W	5101	4822 157 11813	3.3μH 5%
3223	4822 051 20759	75Ω 5% 0.1W	3532	4822 117 11507	6k8 1% 0.1W	5202	4822 157 11139	6.8μH 5%
3224	4822 051 20759	75Ω 5% 0.1W	3534	4822 117 13579	220k 1% 0.1W	5202	4822 157 11813	3.3μH 5%
3225	4822 051 20104	100k 5% 0.1W	3536	4822 051 20273	27k 5% 0.1W	5204	4822 157 11866	1.8μH 10%
3226	4822 051 20334	330k 5% 0.1W	3536	4822 117 10834	47k 1% 0.1W	5260	4822 157 71401	27μH
3227	4822 116 52228	680Ω 5% 0.5W	3537	4822 117 10833	10k 1% 0.1W	5401	4822 157 53995	100U 10%
3228▲	4822 051 20101	100Ω 5% 0.1W	3538	4822 116 52234	100k 5% 0.5W	5404	4822 157 11891	27μH 10%
3229	4822 117 11504	270Ω 1% 0.1W	3539	4822 116 52251	18k 5% 0.5W	5404	4822 157 11894	56μH 10%
3233	4822 116 52219	330Ω 5% 0.5W	3540	4822 100 12156	4k7 30%	5405	4822 157 11213	22μH
3234	4822 051 20331	330Ω 5% 0.1W	3541▲	4822 053 11479	47Ω 5% 2W	5406	4822 157 11076	LINEARITY COIL
3235	4822 051 20331	330Ω 5% 0.1W	3542▲	4822 053 21475	4M 7% 0.5W	5408	4822 157 11213	COIL 22μH
3236▲	4822 051 20101	100Ω 5% 0.1W	3570▲	4822 051 20109	10Ω 5% 0.1W	5408	4822 157 71401	27μH
3243	4822 117 12955	2k7 1% 0.1W	3600	4822 116 52213	180Ω 5% 0.5W	5410	4822 157 71401	27μH
3246	4822 116 52283	4k7 5% 0.5W	3601	4822 116 83881	390Ω 5% 0.5W	5444▲	4822 146 21116	LINE DRIVE TRAFO
3247	4822 116 52175	100Ω 5% 0.5W	3602	4822 116 83883	470Ω 5% 0.5W	5445▲	4822 140 10669	LOT
3248	4822 116 52175	100Ω 5% 0.5W	3603	4822 116 52263	2k7 5% 0.5W	5501▲	4822 157 11399	30mH
3257	4822 051 20479	47Ω 5% 0.1W	3605	4822 117 11503	220Ω 1% 0.1W	5502	4822 526 10704	100mH
3258	4822 051 20479	47Ω 5% 0.1W	3606	4822 051 20561	560Ω 5% 0.1W	5516	4822 157 60171	Bead EMI 100MHz 83R
3259	4822 051 20479	47Ω 5% 0.1W	3607	4822 117 10833	10k 1% 0.1W	5521	4822 157 62552	2.2μH
3260	4822 051 10102	1k 2% 0.25W	3608▲	4822 051 20471	470Ω 5% 0.1W			
3266▲	4822 051 20153	15k 5% 0.1W	3608	4822 117 11504	270Ω 1% 0.1W			
3268	4822 051 20333	33k 5% 0.1W	3609	4822 117 11454	820Ω 1% 0.1W			
3269	4822 051 20393	39k 5% 0.1W	3610▲					

5540	4822 157 11835	4.7μH 5%
5545▲	4822 140 10668	LOT 14"
5545▲	4822 140 10671	LOT 20"/21"
5550	4822 157 60171	Bead EMI 100MHz 83R
5551	4822 157 71401	27μH
5552	4822 526 10704	100mH
5570	4822 526 10704	100mH
5571	4822 157 50961	22μH
5573	4822 157 60171	Bead EMI 100MHz 83R
5603	4822 157 11139	6.8μH 5%
5604	4822 157 11895	4.7μH 10%



6003	4822 130 83757	BAS216
6004	4822 130 83757	BAS216
6005	4822 130 30621	1N4148
6006	4822 130 30621	1N4148
6007	4822 130 34142	BZX79-B33
6008	4822 130 10414	BA792
6009	4822 130 10414	BA792
6107	4822 130 10852	BZX284-C6V8
6110	4822 130 10852	BZX284-C6V8
6211	4822 130 31983	BAT85
6212	4822 130 30621	1N4148
6213	4822 130 30621	1N4148
6214	4822 130 30621	1N4148
6215	4822 130 30621	1N4148
6216	4822 130 10256	EGP20DL-5300
6400	4822 130 30621	1N4148
6401	4822 130 30621	1N4148
6402	4822 130 42488	BYD33D
6404	4822 130 32896	BYD33M
6405	4822 130 42488	BYD33D
6406	4822 130 30621	1N4148
6409	4822 130 42488	BYD33D
6410	4822 130 42488	BYD33D
6412	4822 130 42488	BYD33D
6413	4822 130 34197	BZX79-B12
6414	4822 130 83757	BAS216
6415	4822 130 83757	BAS216
6418	4822 130 30621	1N4148
6419	4822 130 30621	1N4148
6431	4822 130 30842	BAV21
6432	4822 130 30621	1N4148
6435	4822 130 83757	BAS216
6460	4822 130 42488	BYD33D
6461	4822 130 34142	BZX79-B33
6502	4822 130 31083	BYW55
6503	4822 130 31083	BYW55
6504	4822 130 31083	BYW55
6505	4822 130 31083	BYW55
6507	4822 130 42606	BYD33J
6508	4822 130 42606	BYD33J
6537	4822 130 30842	BAV21
6540	4822 130 30842	BAV21
6550	4822 130 10218	SBYV27-200
6560	4822 130 10871	SBYV27-200
6570	4822 130 10256	EGP20DL-5300
6600	4822 130 11366	BZX284-C3V9
6601	4822 130 10852	BZX284-C6V8
6603	4822 130 31983	BAT85
6604	4822 130 31983	BAT85
6605	4822 130 31983	BAT85
6612	4822 130 34278	BZX79-B6V8
6669	4822 130 34233	BZX79-B5V1
6680▲	4822 130 10859	TLDR5400
6953	4822 130 11411	BZX284-C3V3



7000	4822 130 60511	BC847B
7001	4822 130 60511	BC847B
7002	4822 130 60511	BC847B
7010	4822 209 90008	L78M05CP
7130	5322 130 42755	BC847C
7131	5322 130 42755	BC847C
7132	5322 130 42755	BC847C
7133	5322 130 42755	BC847C
7140	4822 130 60511	BC847B
7141	4822 130 60511	BC847B
7250	4822 209 16775	TDA8842/N2/S1
7250	4822 209 17458	TDA8845PS/N1
7250	4822 209 17539	TDA8841/N2/S1
7254	5322 130 42755	BC847C
7256	4822 130 60511	BC847B
7266	4822 130 60511	BC847B
7400	4822 130 41782	BF422
7401	5322 130 60508	BC857B
7402▲	4822 130 11575	BUT11APX

7431	5322 130 60508	BC857B
7460	4822 209 13176	TDA9302H
7469	4822 130 60511	BC847B
7518▲	4822 130 10806	STP6NA60FI
7518	4822 130 63787	STP4NA60FI
7520	4822 209 15684	MC44603AP
7600	4822 209 17467	SAA5564PS/M2A/0015
7600	4822 209 17468	SAA5564PS/M2A/0016
7601▲	4822 209 15546	ST24W08B6
7602▲	4822 130 41109	BD135-16
7605	4822 130 60511	BC847B
7607	5322 209 60154	NE555D
7608▲	4822 209 73852	PMBT2369
7609	4822 130 60511	BC847B
7610	4822 130 60511	BC847B
7611	4822 130 60511	BC847B
7612▲	4822 130 41109	BD135-16
7620	4822 130 40959	BC547B
7621	4822 130 60511	BC847B
7680	4822 218 12055	TSOP2836UH1
7703	4822 130 60511	BC847B
7704	4822 130 60511	BC847B
7705	4822 209 31555	TDA9830/V1
7951	4822 130 60511	BC847B
7952	4822 130 60511	BC847B
7953	4822 209 90462	TDA7056B/N1
7955	4822 130 60511	BC847B
7956	5322 130 60508	BC857B
9103	4822 157 11235	LAN02TB220J
9245	4822 526 10704	Bead EMI 50MHz 45R

CRT[B]

Various

0254▲	4822 255 70293	CRT socket 14"
0254▲	4822 267 20466	Conn. 9P
1015	4822 212 11998	CRT PANEL



2313	4822 122 33216	270pF 5% 50V
2323	4822 122 33172	390pF 5% 50V
2331	4822 122 33805	330pF 10% 63V
2341▲	4822 126 14588	2.2nF 10% 1KV
2342	4822 121 43526	47nF 5% 250V
2343	4822 121 43526	47nF 5% 250V



3311	4822 051 10102	1k 2% 0.25W
3312	4822 051 20331	330Ω 5% 0.1W
3313▲	4822 051 20109	10Ω 5% 0.1W
3313	4822 051 20478	4Ω7 5% 0.1W
3314	4822 053 12183	18k 5% 3W
3316▲	4822 052 10221	220Ω 5% 0.33W
3317	4822 117 11896	1k5 20% 0.5W
3321	4822 051 10102	1k 2% 0.25W
3322	4822 051 20331	330Ω 5% 0.1W
3323▲	4822 051 20109	10Ω 5% 0.1W
3323	4822 051 20478	4Ω7 5% 0.1W
3324	4822 053 12183	18k 5% 3W
3326▲	4822 052 10221	220Ω 5% 0.33W
3327	4822 117 11896	1k5 20% 0.5W
3331	4822 051 10102	1k 2% 0.25W
3332	4822 051 20331	330Ω 5% 0.1W
3333▲	4822 051 20109	10Ω 5% 0.1W
3333	4822 051 20478	4Ω7 5% 0.1W
3334	4822 053 12183	18k 5% 3W
3336▲	4822 052 10221	220Ω 5% 0.33W
3337	4822 117 11896	1k5 20% 0.5W
3341	4822 117 11896	1k5 20% 0.5W
3347	4822 052 10102	1k 5% 0.33W
3348	4822 117 11896	1k5 20% 0.5W
3349▲	4822 052 10108	1Ω 5% 0.33W
3349▲	4822 052 10128	1Ω2 5% 0.33W
3349▲	4822 052 10158	1Ω5 5% 0.33W
3350▲	4822 052 10108	1Ω 5% 0.33W
3350▲	4822 052 10128	1Ω2 5% 0.33W
3350▲	4822 052 10158	1Ω5 5% 0.33W



5341	4822 157 50961	22μH
5341	4822 157 50965	15μH 10%
5341	4822 157 71915	5.6μH
5342	4822 526 10704	100mH



6311	4822 130 30842	BAV21
6321	4822 130 30842	BAV21
6331	4822 130 30842	BAV21
6341	4822 130 30842	BAV21
6342	4822 130 30621	1N4148
6343	4822 130 11666	BZX284-C8V2



7311	4822 130 41782	BF422
7312	4822 130 41782	BF422
7313	4822 130 41646	BF423
7321	4822 130 41782	BF422
7322	4822 130 41782	BF422
7323	4822 130 41646	BF423
7331	4822 130 41782	BF422
7332	4822 130 41782	BF422
7333	4822 130 41646	BF423

SOUND[D]

Various

0239	4822 267 11052	Conn. 17P
0240	4822 267 11052	Conn. 17P
0248	4822 267 10735	Conn. 3P
1040▲	4822 212 11994	Audio panel Nicam/2CS/ Headphone
1063▲	4822 212 11994	Audio panel Nicam/2Cs/ Headphone
1801	4822 242 10769	X-tal 18.432MHz



2801	5322 122 32658	22pF 5% 50V
2804	4822 122 33926	12pF 50V
2805	5322 126 10225	1P5 5%
2806	5322 126 10225	1P5 5%
2807	4822 126 13061	220nF 20% 25V
2808	4822 126 13061	220nF 20% 25V
2809	4822 126 13061	220nF 20% 25V
2810	4822 126 13061	220nF 20% 25V
2814	4822 126 10002	100nF 20% 25V
2815	4822 126 13692	47pF 1% 63V
2820	4822 124 41579	10μF 20% 50V
2821	4822 126 10002	100nF 20% 25V
2822	4822 124 41579	10μF 20% 50V
2823	4822 126 10002	100nF 20% 25V
2824	4822 124 41579	10μF 20% 50V
2825	4822 126 10002	100nF 20% 25V
2827	4822 124 41579	10μF 20% 50V
2828	5322 126 10511	1nF 5% 50V
2829	4822 124 40769	4.7μF 20% 100V
2830	5322 126 10511	1nF 5% 50V
2831	4822 124 41579	10μF 20% 50V
2835	4822 126 10002	100nF 20% 25V
2836	4822 126 10002	100nF 20% 25V
2837	5322 122 32531	100pF 5% 50V
2838	5322 122 32531	100pF 5% 50V
2841	4822 124 81029	100μF 20% 25V
2842	4822 124 81029	100μF 20% 25V
2950	4822 124 81151	22μF 50V
2951	4822 124 41579	10μF 20% 50V
2952	4822 122 33891	3.3nF 10% 63V
2953	4822 126 13061	220nF 20% 25V
2954	5322 121 42386	100nF 5% 63V
2955	4822 124 11767	470μF 20% 25V
2962	4822 122 33891	3.3nF 10% 63V
2963	4822 126 13061	220nF 20% 25V
2965	4822 126 13061	220nF 20% 25V



3807	4822 116 52175	100Ω 5% 0.5W
3808	4822 116 52175	100Ω 5% 0.5W
3809	4822 117 10834	47k 1% 0.1W
3810▲	4822 051 20101	100Ω 5% 0.1W
3811▲	4822 051 20101	100Ω 5% 0.1W
3812▲	4822 052 10688	6Ω8 5% 0.33W
3899▲	4822 051 20472	4k7 5% 0.1W
3899	4822 051 20562	5k6 5% 0.1W
3950	4822 051 20273	27k 5% 0.1W
3953▲	4822 051 20332	3k3 5% 0.1W
4xxx	4822 051 10008	0Ω 5% 0.25W

GB 58**10.****L9.2E**

4xxx 4822 051 20008 0Ω 5% 0.25W


5801 4822 157 50965 15μH 10%
5811 4822 157 51462 10μH 10%
5812 4822 157 51462 10μH 10%
5813 4822 157 51462 10μH 10%
5814 4822 157 53139 4.7μH



6801 4822 130 30621 1N4148
6802 4822 130 34382 BZX79-B8V2
6953 5322 130 31504 BZX79-B3V3



7803 4822 209 17461 MSP3415D-PP-A2
7953 4822 209 13646 TDA7057AQ/N2
7956 5322 130 60508 BC857B

SIDE AV[E]

Various

0021 4822 402 11366 SIDE AV BRKT. 21"
0250 4822 265 11606 Conn. 3P
0251 4822 267 10735 Conn. 3P
0252 4822 267 10565 Conn. 4P
0253 4822 267 10735 Conn. 3P
1050 4822 212 11996 SIDE AV PANEL



2171 4822 126 13512 330pF 10% 50V
2172 4822 126 13512 330pF 10% 50V



3150 4822 116 83884 47k 5% 0.5W
3151 4822 050 11002 1k 1% 0.4W
3152 4822 116 83884 47k 5% 0.5W
3153 4822 050 11002 1k 1% 0.4W